PRONAR Sp. z o.o.



17-210 NAREW, ul. Mickiewicza 101A; Region of Podlasie

tel./fax: fax:

x: 0(85) 681 63 29; 0(85) 681 64 29; 0(85) 681 63 81; 0(85) 681 63 82; 0(85) 681 63 84; 0(85) 681 63 83; 0(85) 682 71 10;

www.pronar.p I

# AGRICULTURAL MONOCOQUE TRAILER / DUMPER "TANDEM"

**T669** 

# **OPERATION & MAINTENANCE MANUAL**

Identification of the machine

Symbol /Type: KTM Symbol: Serial: T669 1026-634-847-708

.....

The serial is stamped on the type plate and on the front of the trailer's frame. The type plate is riveted to the load-carrying body.

In the course of purchase check conformity of the serial stamped on the trailer with the serial given in the warranty card, in purchase documents and in the operation manual.

Hydraulic system is filled with HL32 hydraulic oil

Quality Inspection Sign.....

The manual and the spare parts catalogue are valid together with the annex No. ..... from the ......

The manufacturer reserves the right to introduce design modifications for the purpose of simplified maintenance and improved operation quality.

Remarks and notices about design and operation of the trailer should be submitted to the manufacturer. This information allows us to evaluate objectively manufactured machines and will be used as hints for further modernisation.

Information about major design alterations will be supplied to users in the form of enclosed information leaflets (annexes).

#### CAUTION!

The operation & maintenance manual is the substantial equipment of the trailer.

# The user should read carefully the manual before operation and observe all recommendations given in the manual. This will ensure safe maintenance and failure-free operation of the machine.

The machine has been designed in accordance with generally recognised standards, documents and currently binding legal regulations.

Product verified by the IBMER – the research lab authorised by the PCA





# CONTENTS

1	INTR		4
	1.1	GENERAL INFORMATION	4
	1.2	APPLICATION OF THE TRAILER	4
2	OPE	RATIONAL SAFETY	5
	2.1	PRINCIPLES OF USE OF PUBLIC ROADS	7
3	ADD	ITIONAL INFORMATION	9
	3.1	TRAILER EQUIPMENT	9
	3.2	WarRANTY CONDITIONS	9
	3.3	TransportATION	9
4	OPE	RATIONAL INFORMATION	11
	4.1	TECHNICAL DATA	11
	4.2	TRUCTURE AND OPERATIONAL PRINCIPLE	12
	4.2.	1 Undercarriage	
	4.2.	2 Load crate	13
	4.Z. 4.2	A Braking system	13 15
	4.2.	5 Wiring, lighting, signalling	
	4.3	TRAILER OPERATION PRINCIPLES	19
	4.3.	1 Coupling with tractor	19
	4.3.	2 Preparation for work	20
	4.3.	3 Loading the load crate.	
	4.3. 4.3	<ul> <li>4 Transport</li> <li>5 Tyre maintenance manual</li> </ul>	21 21
	4.3.	6 Load crate unloading	
	4.3.	7 Uncoupling the tractor.	23
	4.3.	8 Failures and defects	23
5	MAIN		24
	5.1	ADJUSTMENT OF WHEEL BEARINGS	24
	5.2	ADJUSTMENT OF BRAKES	26
	5.3	MAINTENANCE OF PNEUMATIC SYSTEM	27
	5.4	MAINTENANCE OF HYDRAULIC SYSTEM	27
	5.5	LUBRICATION	28
	5.6	ASSEMBLY / DISASSEMBLY OF SUPERSTRUCTURES	31
	5.7	STORAGE & PRESERVATION	35

# **1 INTRODUCTION**

## 1.1 GENERAL INFORMATION

The manual describes basic rules of safe operation & maintenance of the agricultural trailer. If information contained within the manual will be not comprehensible for the user please do not hesitate to contact your dealer or directly the manufacturer.

Especially important are information and recommendation marked in the text by bold characters or preceded by the word "CAUTION".

Information, descriptions of danger and precautions as well as commands and orders concerning safe operations are marked with following sign:



and mentioned in the chapter "Safe operation ".

## **1.2 APPLICATION OF THE TRAILER**

The trailer is designed for transportation of agricultural produce as well as loose and volume materials within farm limits and on public roads.

Brake, lighting and signalling systems fulfil all requirements of traffic regulations.

The trailer is adapted for coupling with agricultural tractors fitted with external hydraulic system and a hook for single-axle trailers.



# CAUTION!

The trailer must not be used contrary to its proper application and especially:

- for transporting of persons & animals,
- for transporting of loose, unprotected toxic materials if there is the possibility of environment contamination,
- for transporting of machinery & devices, which location of gravity centre may influence negatively on trailer's stability,
- for transporting of loads, which may cause unequal load or overload of axles,
- for transporting of non-fastened loads, which may change their location on the trailer's platform during drive.

# 2 OPERATIONAL SAFETY



- The user should read carefully the manual before operation and observe all recommendations given in the manual during operation.
- If information contained within the manual will be not comprehensible for the user please do not hesitate to contact your dealer, who also provides repair & service or directly the manufacturer.
- Careless and improper operation & maintenance of the trailer as well as lack of observation of recommendations given in present manual may endanger human health and life.
- Lack of observation of safe use rules may endanger health of operators and third persons.
- There is the risk of residual danger, thus application of safe operation rules should be the basic principle of trailer's use.
- Persons unauthorised for driving agricultural tractors including children and drunken persons have no right to use the trailer.
- It is prohibited to use the trailer contrary to its purposes. User, who utilise the trailer in other than prescribed manner, takes all responsibility for all consequences resulting from trailer's use.
- Any unauthorised modification absolves the PRONAR Narew from responsibility for resulting damage or health detriment.
- Prior to each trailer's use check its technical condition, especially coupling system, drive system, brakes and signalling lights.
- Check trailer's hydraulic system frequently; any oil leakage is inadmissible.
- Take special care while coupling trailer with tractor.
- For coupling with tractor use only hooks for single-axle trailers. Check safety device.
- In the course of coupling no one is allowed to stand between trailer and tractor.
- Climbing on the trailer is allowed only if the trailer is completely stopped and tractor's engine off; the trailer should be also braked with its hand brake.
- Disconnection of the trailer while the load crate is lifted with the telescope cylinder is prohibited. Take special care by disconnecting the trailer.
- Disconnected trailer should be braked. If the trailer stands on a slope or an elevation it should be protected additionally with wedges or other blunt-edged objects placed under wheels.
- The load should be placed uniformly on the load crate surface.

- Admissible load must not be exceeded.
- Driving with lifted load crate and transporting of people & animals is prohibited.
- No one is allowed to stand in the vicinity of lifted load crate and unloaded material.
- Keep safe distance from electric lines while lifting the load crate.
- If any operation failure or damage occurs, stop operation of the trailer and repair the damage.
- Maintenance & repair of the trailer with loaded and/or lifted load crate without proper support of the crate is prohibited.
- During trailer's operation use protection gloves and proper tools.
- All maintenance & repair works should be performed with observation of safety regulations. In the case of wound wash and disinfect wounded place immediately. In the case of serious injuries consult a physician.
- The trailer is marked with information / signalling stickers as described in the table 1 below. The user should take care of legibility and cleanliness of inscriptions & warnings for all time of trailer's operation. In the case of damage or destruction replace missing stickers with new ones available at your dealer or manufacturer.

Safety sign or text	Explanation	Location	
	Read operation manual	Front wall	
	Prior to maintenance & repair stop the engine and remove the ignition key	Front wall	
	Prior to maintenance & repair secure the load crate	Right & left wall	

#### Table 1. Information & warning stickers

Table 1.	Information	&	warning	stickers,	continued
----------	-------------	---	---------	-----------	-----------

Safety sign or text	Explanation	Location	
	Take special precautions while operating near to energetic lines	Right & left wall	
	Take special precautions while opening / closing the rear flap	Right & left wall	
(for hydraulic systems of I and II trailer)		Cut-off valve	
Load: With superstructures 13500 kg W/o superstructures 14100 kg		Right & left wall	
25 kN	Minimum vertical load of tractor's hitch	Hitch rod	
280 kPa	Tyre pressure 50x20.0 R22 32PR	Above wheels, right & left wall	
210 kPa	Tyre pressure 550/60-22.5 12PR	Above wheels, right & left wall	
280 kPa	Tyre pressure 550/60-22.5 16PR	Above wheels, right & left wall	
800 kPa	Tyre pressure 385/65-22.5 18PR	Above wheels, right & left wall	

# 2.1 PRINCIPLES OF USE OF PUBLIC ROADS

- While driving public roads observe traffic regulations.
- Trailer's overload may cause its damage and endanger traffic safety.
- Do not exceed the maximum speed of 30 kph. Adjust the speed to traffic conditions.
- The trailer can work on slopes up to 8°. Lift the load crate on level ground only.
- It is prohibited to leave unsecured trailer. Always activate the parking brake.
- While driving public roads the trailer should be equipped with certified or approved warning reflecting triangle.

Rear wall should be equipped with a triangular plate for slowly moving vehicles (if the trailer is the last vehicle in a set (Fig. 1)).



Fig. 1 Location of a triangular plate for slowly moving vehicles.

It is prohibited to leave unsecured trailer. Always activate the parking brake.

# **3** ADDITIONAL INFORMATION

## 3.1 TRAILER EQUIPMENT

Trailer equipment consists of:

•	operation & maintenance manual + spare parts catalogue	-	1
•	warranty card	-	1
•	connection cable	-	1
•	load crate support	-	1

For user's order the trailer may be equipped additionally with:

- warning reflecting triangle
- triangular plate for slowly moving vehicles

# 3.2 WARRANTY CONDITIONS

"PRONAR" Sp. z o.o. guarantees efficient operation of the trailer if utilised according to technical & operation conditions described in the manual.

Failures detected within warranty period will be removed by the Warranty Service within no longer than 14 working days from the date of delivery to a repair station or within any other agreed period.

Normally wearing parts i.e. tyres, brake linings as well as mechanical damage, damage resulted from improper use, adjustment or maintenance are not subject of warranty.

Detailed warranty conditions are mentioned in the warranty card supplied together with the newly bought trailer.



# CAUTION!

Demand your dealer to fill the warranty card and complaint coupons exactly and completely. Lack of e.g. sale date or dealer's stamp may render your possible complaint void.

# 3.3 TRANSPORTATION

The trailer is delivered for sale fully assembled and requires no package. Packed are only: the manual, the connection cable and – if ordered – the warning triangle.

The trailer is supplied to the user with a truck or the user can take by himself with his own tractor.



# CAUTION!

If the user takes the trailer by him he should read present manual and observe all recommendations given in the manual. In the case of transportation with a truck the trailer is fastened on the load crate according to generally recognised safety rules. The truck driver should take special precautions while transporting the trailer, because the gravity centre of the loaded truck is shifted upwards.

# 4 OPERATIONAL INFORMATION

# 4.1 TECHNICAL DATA

Table 2. Basic technical data

	Data		T669 with various tyre variants				
No.			50x20.0R22 32PR	550/60-22.5 12PR	550/60-22.5 16PR	385/65-R22.5 18PR	
1	Overall length	mm	7103	7103	7103	7103	
2	Overall width	mm	2550	2550	2550	2550	
3	Overall height w/o superstructures	mm	2754	2764	2764	2680	
4	Overall height with superstructures	mm	3334	3344	3344	3260	
5	Wheel base	mm	1920	1900	1900	1900	
6	Load crate internal dimensions:						
	<ul> <li>length (lower/upper)</li> </ul>	mm	5500/5760	5500/5760	5500/5760	5500/5760	
	<ul> <li>width (front / rear)</li> </ul>	mm	2200/2250	2200/2250	2200/2250	2200/2250	
	<ul> <li>height w/o superstructures</li> </ul>	mm	1200	1200	1200	1200	
	<ul> <li>height with superstructures</li> </ul>	mm	1780	1780	1780	1780	
7	Load volume (with superstructures)	m³	22.4	22.4	22.4	22.4	
8	Load surface	m²	12.2	12.2	12.2	12.2	
9	Load surface height above ground	mm	1511,5	1521,5	1521,5	1436,5	
10	Weight w/o superstructures	kg	5900	5900	5900	5900	
11	Weight with superstructures	kg	6500	6500	6500	6500	
12	Admissible load w/o superstructures	kg	14100	14100	14100	14100	
13	Admissible load with superstructures	kg	13500	13500	13500	13500	
14	Load crate tilt angle	(°)	50	50	50	50	
15	Tyre pressure	kPa	280	210	280	800	
16	Rated voltage	V	12	12	12	12	
17	Admissible speed	km/h	30	30	30	30	
18	Hydraulic oil capacity	I	29	29	29	29	

Table 3.	Tyres –	technical	data
----------	---------	-----------	------

Tyre	Load index			Rolling	Rolling Load [kg] at speed [kph]				
dimensions (+ PR number)	& speed symbol	Tread	Ring	radius [mm]	30	40	other	[kPa]	Notes
50x20.0 R22 32PR	170 A8	Rib	16.00x22	605	6420	6000		280	
550/60-22.5 12PR	164 A8	TR 08	16.00x22.5	544	5350	5000		210	Vredestein
550/60-22.5 16PR	163 A8	TR 08	16.00x22.5	542	5216	4875		280	Mitas
15.0 R22.5 18PR (385/65R R22.5)	160F	Y-1	11.75x22.5	485	5125	4715	4100 (80 km/h)	800	Guma Bolechowo

### 4.2 TRUCTURE AND OPERATIONAL PRINCIPLE

## 4.2.1 Undercarriage



Fig. 2 Undercarriage.

1 – lower frame, 2 – hydraulic cylinder, 3 – hitch rod, 4 – load crate, 5 – load crate support, 6 –hydraulic support, 7 - axle.

Trailer's undercarriage consists of parts shown on the Fig. 2. The lower frame (1) is a welded structure made of steel profiles. Main carrying elements are two stringers connected each to other with cross-bars. The middle part is fitted with a seat for hydraulic cylinder (2). The rear part of the frame is fitted with elements for fastening of axle, elements connecting the lower frame with the load crate (4) and elements of rear lighting assembly.

Axles (7) are made of a square rod with pivots on either end; on pivots are mounted conical bearings and on bearings – wheel hubs. The wheels are of single type, fitted with shoe brakes actuated with brake cams.



Fig. 3 Load crate elements.

1 – load crate, 2 – side superstructures, 3 – rear superstructure, 4 – front superstructure, 5 – rear flap, 6 – chute flap

#### 4.2.3 Hydraulic tilting system

Hydraulic tilting system is designed for automated unloading of the trailer through raising of the rear flap and tilting the load crate backwards. The hydraulic system is supplied with oil from tractor's hydraulic system and consists of two separate circuits: for raising / lowering the load crate and for raising / lowering the rear flap.

The circuit for raising / lowering the load crate consists of hydraulic conduits, hydraulic cylinder, cut-off valve and control cable for the cut-off valve.

The purpose of the cable (7) is to cut-off the flow of hydraulic oil to the cylinder (1) through switch-over of the cut-off valve (2) if maximum tilt angle is exceeded. The hydraulic system diagram is shown on the fig. 4.



Fig. 4 Load crate tilt hydraulic system.

1 – hydraulic cylinder, 2 – cut-off valve, 3 – connection valve plug, 4 – flexible conduits, 5 - roller, 6 – rigid hydraulic conduits, 7 – cut-off valve control cable

# CAUTION!

The cut-off valve 2 (Fig. 4) reduces load crate tilting angle while tilted sidewards. The length of the cable rope is adjusted by the manufacturer and must not be readjusted by the user.

The circuit for raising / lowering the rear flap consists of two double-action hydraulic cylinders and hydraulic conduits. When the system works, cylinders control operation of locking hooks. When the rear flap is closing, locking hooks lock it (pos. (a), fig. 5).

# CAUTION!

When the rear flap is lowered the locking hook must lock completely the locking bolt of the rear flap (3) (fig. 5).



Fig. 5 Operation of the rear flap.

1 – double-action hydraulic cylinder, 2 – locking hook, 3 – rear flap locking bolt

### 4.2.4 Braking system

The trailer is fitted with a braking system, which consists of:

- pneumatically controlled operational brake
- manually operated (crank-operated) parking brake

The operational brake (pneumatic) is actuated from driver's seat with a brake pedal. In the case of disconnection from tractor's pneumatic system of the brake is actuated automatically.



Fig. 6 Two-conduit pneumatic braking system with automated braking force controller.

1 - air reservoir, 2 - control valve, 3 - pneumatic cylinder, 4 - connector (yellow) of the control conduit for coupling with the tractor, <math>5 - connector (red) of the supply conduit for coupling with the tractor, 6 - connector (yellow) of the control conduit for coupling with second trailer, 7 - connector (red) of the supply conduit for coupling with second trailer, 9 - air filter, 10 - air reservoir inspection connector, 11 - drain valve



**Fig. 7** Two-conduit pneumatic braking system with three-range braking force controller. 1 – air reservoir, 2 – control valve, 3 – pneumatic cylinder, 4 – connector (yellow) of the control conduit for coupling with the tractor, 5 – connector (red) of the supply conduit for coupling with the tractor, 6 – connector (yellow) of the control conduit for coupling with second trailer, 7 – connector (red) of the supply conduit for coupling with second trailer, 8 – three-range braking force controller, 9 – air filter, 10 – air reservoir inspection connector złącze, 11- drain valve

# 4.2.5 Wiring, lighting, signalling

The wiring system is adapted for power supply with 12 V DC. Trailer and tractor electrical systems should be connected together with suitable connection conduit.



Fig. 8 Wiring system diagram.

PP (PL) - right (left) front position light, ZP (ZL) – rear compact lamp right (left), OTP (OTL) – panel lighting lamp right (left), GP (GT) – front (rear) seven-pin socket, TOP (TOL) – rear contour lamp right (left), OBP (OBL) – side contour lamp right (left)

1 – central bundle, 2 – front bundle (Polish version), 3 – front bundle (Danish version), 4 – rear bundle



Fig. 9 Connection of conductors.

#### **Conductor colours**

p-orange, c-black, k-red, r-rose, n-blue, c/t-black-green, t-green,

31 – frame, R (L) – right (left) blinker, 58R (58L) – right (left) position lamp, 54 - "STOP", "+" – power supply +12V DC

# 4.3 TRAILER OPERATION PRINCIPLES

#### 4.3.1 Coupling with tractor

Prior to coupling with tractor check if the trailer is braked with the parking brake. The tractor should be fitted with a tow hook, which is able to carry min. 25 kN (2500 kg) vertical load.

To couple trailer with tractor it is necessary to perform following operations:

- Position the hitch rod eye on suitable level.
- Precise adjustment of the hitch rod can be achieved with help of the hydraulic support. For this purpose draw back the tractor and connect the hydraulic support conduit to the tractor; then open the support securing valve and position the hitch rod eye.
- Draw back the tractor, couple hitch rod eye with the lower tow coupling on the tractor and check its fastening.
- Raise the support
- Connect electrical, hydraulic (tilt + rear flap) and brake conduits to the tractor.
- Unlock the trailer parking brake.



# CAUTION!

In the course of coupling no-one except of operator is allowed to stand between trailer and tractor.

# 4.3.2 Preparation for work

During preparation for work it is necessary to check following items:

- condition of tyres and tyre pressure
- fastening of nuts fixing wheels and hitch rod
- condition of other screw connections
- function of lighting & signalling systems
- function of braking system
- function of hydraulic tilting system

### 4.3.3 Loading the load crate.

It is allowed to load the crate only if it is coupled with a tractor and stands on the level ground. Loading should be arranged uniformly on the entire load crate floor, if possible.

It is recommended to use a crane, a loader or a conveyor for loading. Prior to loading check if the chute of the rear flap is closed.

In the case of objects, which put pressure in a few points only use thick boards as separators. Table 4 contains admissible loading heights of various materials. The table shows clearly that – in many cases – it is impossible to use the entire loading volume without exceeding the admissible load. It is important not to overload the trailer during loading.

Lightweight materials of great volume may be loaded above wall height but the load should be properly secured from falling down and polluting the road.

Type of material	Loading height [m]
wet gravel, wet soil, clinker, stone	0,6
cement, dry gravel, soil, brick	0,7
manure, full brick, mineral fertiliser	1,2
rye, potatoes, maize, rape, wheat	1,5
barley, oats, peat, coke	1,8



# CAUTION!

It is prohibited to exceed the admissible trailer load. Overload may endanger traffic safety and damage the trailer.

### 4.3.4 Transport

- While driving public roads observe traffic regulations.
- Trailer's overload may cause its damage and endanger traffic safety.
- Do not exceed the maximum speed of 30 kph. Adjust the speed to traffic conditions.
- The trailer can work on slopes up to 8°. Lift the load crate on level ground only.
- It is prohibited to leave unsecured trailer. Always activate the parking brake.
- While driving public roads the trailer should be equipped with certified or approved warning reflecting triangle.
- Rear wall should be equipped with a triangular plate for slowly moving vehicles (if the trailer is the last vehicle in a set (Fig. 2)).

#### 4.3.5 Tyre maintenance manual

- During assembly & disassembly of tyres protect the trailer against unintended movements.
- Repair or replacement of tyres should be performed by trained personnel and with suitable tools.
- After each wheel mounting tighten the nuts after first 10 hrs and check their tightening every next 50 hrs.
- Regularly check and preserve proper tyre pressure according to the manual (especially after longer standstills).
- Check the tyre pressure also during intensive daily work. Take into consideration the fact that the increase of tyre temperature may cause tyre pressure growth even by 1 bar. In the case of such pressure & temperature increase reduce the load or / and speed.
- Never reduce the tyre pressure through inflation valves if the pressure has grown due to the temperature.

- Protect tube inflation valves with suitable nuts to avoid penetration of impurities.
- Do not exceed the maximum trailer's speed.
- In the course of daily work make at least one hour lasting pause at noon.
- Make 30 minutes lasting pauses for cooling down the tyres after each 75 km or 150 minutes of continuous drive depending on which occurs first.
- Avoid holes, sudden and violent manoeuvres and reduce speed during turning.

# 4.3.6 Load crate unloading

Unloading is performed through tilting the load crate backwards. Automated unloading should be executed as follows



# CAUTION!

It is prohibited to raise loaded crate when the flap is closed.

Automated unloading should be executed as follows:

- Place the trailer on flat ground, brake the tractor and the trailer with the parking brake. During unloading the tractor should be positioned as to drive forward.
- Open the rear flap with help of hydraulic cylinders.
- Tilt the load crate by raising it with the hydraulic cylinder.



### CAUTION!

- It is allowed to tilt the load crate only when the trailer stands on hard, flat ground.
- During unloading no-one is allowed to stand in the vicinity of tilted load crate.
- It is allowed to tilt the load crate only if the trailer is coupled with a tractor.
- It is prohibited to tilt the load crate during violent wind gusts.

The rear wall is fitted with a chute, which opening can be adjusted resulting in slots of various heights. This enables adjustment of output of unloaded loose materials e.g. mineral fertilisers or cereal. To open the chute, first loose the nut of the securing clamp. Having unloaded the trailer lower the load crate.

- Lower the load crate.
- Close the rear flap by controlling relevant circuit from the tractor. Closing / opening the flap is realised with 2 double-action hydraulic cylinders (pos. 1 fig. 5). The rear flap closing should be realised until the flap becomes locked with locking hooks (pos. 2 fig. 5).



**CAUTION!** 

- Take special precautions while closing the rear flap because, otherwise resulting injuries may cause serious health detriment or in certain cases death.
- Take special precautions while closing flap chute to avoid crushing fingers.
- Do not move and/or drive with the load crate in upper position.

# 4.3.7 Uncoupling the tractor.

To uncouple the trailer perform following actions:

- Stop the tractor and the trailer with the parking brake.
- With help of the hydraulic support place the trailer at proper height and secure with the support securing valve.
- Disconnect electric, hydraulic and brake conduits; protect their ends from dirt.
- Uncouple the hitch rod cable from the tractor's towing hook and drive away with the tractor

# 4.3.8 Failures and defects

Frequently appearing failures & defects and troubleshooting are given in the chapter "MAINTENANCE".



## CAUTION!

- If any operation failure or damage occurs, stop operation of the trailer and repair the damage/ remove the failure.
- Maintenance & repair of the trailer with loaded and/or lifted load crate without proper support of the crate is prohibited.
- All maintenance & repair works should be performed with observation of safety regulations. In the case of wound wash and disinfect wounded place immediately. In the case of serious injuries consult a physician.
- If it is necessary to maintain the trailer with lifted load crate (e.g. replacement of the telescope cylinder) commission a specialised workshop to make repair.

# 5.1 ADJUSTMENT OF WHEEL BEARINGS

After first 500 km and after every next 1500-2000 km check and – if necessary – adjust play of wheel bearings.



Couple the trailer with a tractor, brake the tractor, place locking wedges under trailer wheels and raise each wheel with suitable hoist. Place the hoist between bail screws (1), which fasten the suspension spring to the axle. Check play of bearings.

If the play is excessive, dismount the hub cover (2) and remove the cotter pin (4) of the crown nut (3).





While turning the wheel screw the crown nut tight until the wheel stops. Unscrew the nut by 1/3 of turn until the next cotter pin groove will be aligned with the opening in the pivot.

Secure the nut (3) with the cotter pin (4) and mount the hub cover (2). The wheel should turn smooth, without stops and perceptible resistance, which do not result from rubbing between brake shoes and the drum.



# 5.2 ADJUSTMENT OF BRAKES

The brakes should be adjusted if:

- excessive play between shoe and drum appears due to wear of brake shoes; braking efficiency falls down
- Brakes operate uneven and not simultaneously.

If brakes are adjusted properly braking of both wheels should take place in the same moment.

Adjustment of brakes consists in adjustment of position of the brake cam arm (1) (Fig. 11) in relation to the cam shaft (2). For this purpose loose the nut (4) and change position of the arm on the multi-groove end of the shaft (2) towards proper direction i.e.:

- backward if the brake brakes to late
- forward if the brake brakes to soon

Perform adjustment separately for each wheel. After proper brake adjustment cam arms should form the angle of 90° in relation to pneumatic cylinder push rod whilst the braking power is greatest. Parking brake should be adjusted if the brake cable is excessively stretched or if cable clamps are loosened. Cable length should be matched so that by fully loosened parking and working brakes the cable would be loose and hang down by  $1 \div 2$  cm.



Fig. 10 Brake adjustment elements

1 – brake cam arm, 2 – brake cam shaft, 3 – locking plate or sleeve, 4 – securing screw, 5 – adjustment screw



### CAUTION!

With properly adjusted brakes the braking force should be not lower than values given in the Table 5.

Table 5. Braking force

Trailer type	Main brake braking force (kN)	Parking brake braking force (kN)
T669	55,5	33,3

Difference between left and right wheel braking forces must not exceed 30% with assumption that the "100%" means the greater force.



UWAGA!

The trailer braking power is the sum of braking forces of both wheels.

#### 5.3 MAINTENANCE OF PNEUMATIC SYSTEM

In the scope of maintenance operations it is necessary to perform inspection of pneumatic system tightness, especially at all connections. Tightness test should be executed with system pressure rated at ca. 600 kPa (6,0 kg/cm2).

If conduits, sealings or other elements of the system are damaged, air will get out in points of damage with typical hiss or – in the case of small leakages – in the form of small air bubbles. Small leakage can be detected with soap water or washing agent. Damaged sealings or conduits replace with new ones. If the reason of leakage is the damaged pneumatic cylinder – regenerate it.

Periodically remove condensed water from the air tank. For this purpose pull out the drain valve arbour located in the upper part of the tank. Compressed air will push the water out. After loosening the mandrel the valve should close automatically and stop airflow from the tank.

Once a year just before the winter unscrew the drain valve and clean it from accumulated dirt.

#### 5.4 MAINTENANCE OF HYDRAULIC SYSTEM

It is necessary to take as the principle that the oil in the trailer hydraulic system and the oil in the external tractor hydraulic system is of the same type. Application of different oil types is prohibited.

New trailers are filled with HL32 hydraulic oil.

The hydraulic system of the trailer should be absolutely tight. Test of tightness consists in coupling of the trailer with a tractor, activation of the hydraulic cylinder and keeping it in its maximally pulled out position for 30 s.

If oil leaks at connections of hydraulic conduits, screw the connection tightly; if leakage persists – replace the conduit or the connector with a new one. If oil leaks between connections, replace the damaged conduit. Each mechanical damage requires replacement of damaged element.

If the body of the hydraulic cylinder is polluted with oil check the reason of leakage.

While the cylinders are entirely pulled out check all sealings. Small leakage of "sweating off" type are admissible; if drops of oil are observed – stop the operation and repair the failure.



# CAUTION!

Operation of the trailer with leaky tilting hydraulic system is prohibited.

It is prohibited to operate a trailer with lengthened (in relation to manufacturer's adjustment) rope controlling the cut-off valve (8) (Fig. 4, "Hydraulic system of the load crate tilting system")



# CAUTION!

Condition of the hydraulic system should be checked all time during trailer's operation.

If the hydraulic systems is used very intensively (great number of tilts) replace hydraulic conduits every 4 years.

### 5.5 LUBRICATION

The trailer should be lubricated in points shown on fig. 10, and described in the Table 6 "Lubrication points of the trailer".



Fig. 11 Trailer lubrication points.

# Table 6. Trailer lubrication points

No. at fig. 11	Lubrication point	Number of points	Grease type	Frequency & method of lubrication
1	Parking brake screw	1	solid	every 3-4 months
2	Hitch rod bolt	2	solid	every 3-4 months
3	Hitch rod sliding surface	2	solid	every 3-4 months
4	Suspension spring bolt	4	solid	once a month cover with grease
5	Rocker bolts	2	solid	once a month cover with grease
6	Rear tow coupling assembly	1	solid	every 3-4 months
7	Upper ball articulation of the cylinder	1	solid	every 6 months
8	Bolts of mounting of the hydraulic cylinder	2	solid	every 6 months cover bolts with fresh grease
9	Cam shaft sleeves	8	solid	every 6 months
10	Wheel bearings	4	solid	replace grease every 2 years
11	Rear flap cylinder bearings	4	solid	every 3-4 months
12	Locking hook bolts	2	solid	every 3-4 months
13	Chute guide	2	solid	every 3-4 months cover with very thin layer of grease
14	Hitch rod resistance surface	2	solid	once a month
15	Hitch rod rotational pull rod	1	solid	every 3-4 months
16	Tilt sleeves	2	solid	every 3-4 months
17	Suspension spring slide surfaces	4	solid	once a month
18	Flap bolts	4	solid	every 3-4 months
19	Ladder axle	1	solid	every 3-4 months
20	Ladder clamp	1	solid	every 3-4 months cover with very thin layer of grease
21	Brake adjustment screws	4	solid	every 6 months

### 5.6 ASSEMBLY / DISASSEMBLY OF SUPERSTRUCTURES



Fig. 12 Load crate + set of superstructures.

1 – load crate, 2 – front superstructure, 3a – front side superstructures, 3b- rear side superstructures, 4 – superstructure side post, 5 – connecting beam, 6 – rear flap, 7 – rear superstructure, 8- rear superstructure section (left, right), 9 – rear post (left, right), 10 – superstructure ladder, 11 – flap wing (left, right), 12 – string, 13 – superstructure brackets (invisible on the drawing)

a – load crate left front post, b – load crate left rear post, c – flap left post, d – fastening grips







First screw 6 superstructure brackets (13) to the load crate posts and to the flap. While performing this action pay special attention to keeping proper dimensions as shown on schemes. The scheme (1) shows fastening of the bracket to the front left post of the load crate (a) The right bracket should be installed on the front right post of the load crate in the same way.

Install the superstructure brackets (13), on the rear posts of the load crate and on the flap side posts. The scheme (2) shows fastening of brackets on the left rear post of the load crate (b) and on the flap left post (c).

Scheme 3



Install the front superstructure (2). Openings in the superstructure posts should agree with bracket openings. Arms (d), which fasten the superstructure to the load crate, should be put into relevant fastening grips welded to the load crate. Scheme 4



Install both front side superstructures (3a), by putting them into relevant grips (marked with arrows on the scheme Screw side (4)). superstructures (3a) to the front superstructure (2). Screw two side posts (4) and the next pair of rear side superstructures (3b). Screw the side superstructures (3b) and (3a) to posts (4). Install rear superstructure posts: left (9) and right on superstructure brackets (13). Screw the rear pair of side superstructures (3b) to rear posts.

Scheme 5



Fasten the flap rear superstructure (7) to the flap (6) with brackets (13). Screw the rear superstructure sections (8), and right, to the rear left superstructure posts (8). Stiffen the entire structure with two strings (12) on both sides of the load crate. The strings (12) should be screwed to the left & right flap wings and side sections (8) of the rear superstructure.

Scheme (6)



Having installed the superstructures, screw the connection beam (5) to side Screw posts (4). all superstructures (2), (3a), (3b), (7) and posts (4), (5), (6) to the load crate. Finally, fasten the ladder (10)to the front superstructure.

Detailed list of screwed connections is given in the spare parts catalogue. Description of structural elements on assembly schemes refers to the fig. 12 "Load crate + set of superstructures".

Disassembly of superstructures should be performed in opposite order.



CAUTION!

Assembly and disassembly of superstructures and frame should be performed with help of suitable platforms, ladders or ramp. Said appliances should protect the operator against falling down. The operation should be carried out by at least two operators. Take special precautions.



CAUTION!

Lower edges of superstructure posts should agree with upper edges of the load crate (fig. 13, "Inspection of correct superstructure installation."). Otherwise, the flap operation gear and superstructures may be damaged while opening / closing the flap.



Fig. 13 Inspection of correct superstructure installation.

## 5.7 STORAGE & PRESERVATION

After work clean the trailer and wash with water stream. If the varnish coat is damaged, clean such place from rust and dust, degrease, and paint of the same colour and uniform layer thickness. If damaged places will not be painted immediately, cover them with thin layer of grease or anticorrosion agent.

It is recommended to store the trailer in a closed or roofed storage. If the trailer is stored outdoor for long period protect it from atmospheric influence, especially from agents causing corrosion and ageing of tyres.

# AGRICULTURAL MONOCOQUE TRAILER / DUMPER "TANDEM"

**T669** 

# SPARE PARTS CATALOGUE


Fig. 14 Load crate, complete

Compoi	onent name						
		LOAD CR	ATE		Quantity		
Drawin	g No.	No. of comple	te component/part				
	14, 15				ž	<	
No.	Part name		Drawing / standard No.		T669	T669	
1	Load crate		58RPN-03.00.000	1	1	1	
2	Flap cpl.		58RPN-04.00.000	1	1	1	
3	Superstructure, front 580		58RPN-10.01.000	1	1	1	
4	Superstructure, side 580		58RPN-10.02.000	4	4	4	
5	Superstructure, flap 580		58RPN-10.03.000	1	1	1	
6	Ladder , set		58RPN-00.01.000	1	1	1	
7	Window frames		58RPN-00.00.100	2	2	2	
8	Plexiglas plate		58RPN-00.00.009	2	2	2	
9	Sticker "T669"		58RPN-00.00.010	2	2	2	
10	Sticker "Load"		58RPN-00.00.011	2	-	-	
11	Warning sticker I		58RPN-00.00.012	2	2	2	
12	Warning sticker II		58RPN-00.00.013	2	2	2	
13	Information sticker		58RPN-00.00.014	1	1	1	
14	Sticker "210 kPa"		58RPN-00.00.017	2 ⊗	2 ⊗	2 ⊗	
15	Sticker "280 kPa"		58RPN-00.00.018	2	2	2	
16	Sticker "340 kPa"		29RPN-00.00.019	2 ⊗	2 ⊗	2 ⊗	
17	Warning sticker III		58RPN-00.00.020	2	2	2	
18	Type plate		29RPN-00.00.011	1	-	-	
19	Information sticker II		29RPN-00.00.022	1	-	-	
20	Side step		EB20-010 Zn.	3	3	3	
21	Rectangular reflective sticker	, white	DOB35	2	2	2	
22	Rectangular reflective sticker	, yellow	DOB35	6	-	-	
23	Rivet P Al/Fe 3x8		PN-83/M-82971	4	-	-	
24	Screw M8x25 8.8-B-Fe/Zn5		PN-85/M-82105	12	12	12	
25	Screw M6x25-8.8-B-Fe/Zn		PN-85/M-82105	20	20	20	
26	Nut M8-8-B-Fe/Zn5		PN-86/M-82144	12	12	12	
27	Nut M6-8-B-Fe/Zn5		PN-86/M-82144	20	20	20	
28	Washer 8.4-Fe/Zn5		PN-78/M-82005	12	12	12	
29	Washer 6.4-Fe/Zn5		Pn-78/M-82005	20	20	20	
30	Spring washer Z8.2-Fe/Zn5		PN-90/M-82008	12	12	12	
31	Spring washer Z6.1-Fe/Zn5		PN-90/M-82008	20	20	20	

 $\otimes$  - depending on used tyres



Fig. 15 Load crate, complete

Compoi	ponent name						
		LOAD CR	ATE		Quantity		
Drawin	g No.	No. of comple	te component/part				
	14, 15				¥	∢	
No.	Part name		Drawing / standard No.	T669	T669	T669	
1	Load crate		58RPN-03.00.000	1	1	1	
2	Flap cpl.		58RPN-04.00.000	1	1	1	
3	Superstructure, front 580		58RPN-10.01.000	1	1	1	
4	Superstructure, side 580		58RPN-10.02.000	4	4	4	
5	Superstructure, flap 580		58RPN-10.03.000	1	1	1	
6	Ladder , set		58RPN-00.01.000	1	1	1	
7	Window frames		58RPN-00.00.100	2	2	2	
8	Plexiglas plate		58RPN-00.00.009	2	2	2	
9	Sticker "T669"		58RPN-00.00.010	2	2	2	
10	Sticker "Load"		58RPN-00.00.011	2	-	-	
11	Warning sticker I		58RPN-00.00.012	2	2	2	
12	Warning sticker II		58RPN-00.00.013	2	2	2	
13	Information sticker		58RPN-00.00.014	1	1	1	
14	Sticker "210 kPa"		58RPN-00.00.017	2 ⊗	2 ⊗	2 ⊗	
15	Sticker "280 kPa"		58RPN-00.00.018	2	2	2	
16	Sticker "340 kPa"		29RPN-00.00.019	2 ⊗	2 ⊗	2 ⊗	
17	Warning sticker III		58RPN-00.00.020	2	2	2	
18	Type plate		29RPN-00.00.011	1	-	-	
19	Information sticker II		29RPN-00.00.022	1	-	-	
20	Side step		EB20-010 Zn.	3	3	3	
21	Rectangular reflective sticker	, white	DOB35	2	2	2	
22	Rectangular reflective sticker	, yellow	DOB35	6	-	-	
23	Rivet P Al/Fe 3x8		PN-83/M-82971	4	-	-	
24	Screw M8x25 8.8-B-Fe/Zn5		PN-85/M-82105	12	12	12	
25	Screw M6x25-8.8-B-Fe/Zn		PN-85/M-82105	20	20	20	
26	Nut M8-8-B-Fe/Zn5		PN-86/M-82144	12	12	12	
27	Nut M6-8-B-Fe/Zn5		PN-86/M-82144	20	20	20	
28	Washer 8.4-Fe/Zn5		PN-78/M-82005	12	12	12	
29	Washer 6.4-Fe/Zn5		Pn-78/M-82005	20	20	20	
30	Spring washer Z8.2-Fe/Zn5		PN-90/M-82008	12	12	12	
31	Spring washer Z6.1-Fe/Zn5		PN-90/M-82008	20	20	20	

 $\otimes$  - depending on used tyres



Fig. 16 Rear flap fastening

Compoi	nent name				0			
	RE	AR FLAP FA	STENING		Quantity			
Drawin	g No.	No. of comple	te component/part					
16, 17				6		<b>V</b> 6		
No.	Part name		Drawing / standard No.	T66	T66	T66		
1	Left wing, cpl.		58RPN-05.00.000	1	1	1		
2	Right wing, cpl.		58RPN-06.00.000	1	1	1		
3	Locking hook, left		58RPN-00.00.200	1	1	1		
4	Locking hook, right		58RPN-00.00.300	1	1	1		
5	Flap lock sleeve		64RPN-00.00.001	2	2	2		
6	Hook washer		58RPN-00.00.008	2	2	2		
7	Wing roller		58RPN-05.00.001	2	2	2		
8	Screw M16x100-8.8-B-Fe/Zr	15	PN-85/M-82101	2	2	2		
9	Screw M12x100-5.8-B-Fe/Zr	15	PN-85/M-82101	2	2	2		
10	Nut M27x2-05-B-Fe/Zn5		PN-86/M-82153	8	8	8		
11	Self-locking nut M16-8-B-Fe/	Zn5	PN-85/M-82175	2	2	2		
12	Self-locking nut M12-5-B-Fe/	Zn5	PN-85/M-82175	2	2	2		
13	Washer 30 Fe/Zn5		PN-90/M-82004	2	2	2		
14	Washer 17 Fe/Zn5		PN-78/M-82005	4	4	4		
15	Washer 13 Fe/Zn5		PN-78/M-82005	4	4	4		
16	Cotter pin S-Zn 6.3x45		PN-76/M-82001	2	2	2		
17	Nipple M6		PN-76/M-86002	2	2	2		



Fig. 17 Rear flap fastening

Compo	nent name				Quantity			
	RE	AR FLAP	FASTENING		Quantity			
Drawin	ig No.	No. of con	nplete component/part					
	16, 17			6	AD 6	<b>A</b> 6		
No.	Part name		Drawing / standard No.	T66	T66	T66(		
1	Left wing, cpl.		58RPN-05.00.000	1	1	1		
2	Right wing, cpl.		58RPN-06.00.000	1	1	1		
3	Locking hook, left		58RPN-00.00.200	1	1	1		
4	Locking hook, right		58RPN-00.00.300	1	1	1		
5	Flap lock sleeve		64RPN-00.00.001	2	2	2		
6	Hook washer		58RPN-00.00.008	2	2	2		
7	Wing roller		58RPN-05.00.001	2	2	2		
8	Screw M16x100-8.8-B-Fe/Zr	า5	PN-85/M-82101	2	2	2		
9	Screw M12x100-5.8-B-Fe/Zr	า5	PN-85/M-82101	2	2	2		
10	Nut M27x2-05-B-Fe/Zn5		PN-86/M-82153	8	8	8		
11	Self-locking nut M16-8-B-Fe	/Zn5	PN-85/M-82175	2	2	2		
12	Self-locking nut M12-5-B-Fe	/Zn5	PN-85/M-82175	2	2	2		
13	Washer 30 Fe/Zn5		PN-90/M-82004	2	2	2		
14	Washer 17 Fe/Zn5		PN-78/M-82005	4	4	4		
15	Washer 13 Fe/Zn5		PN-78/M-82005	4	4	4		
16	Cotter pin S-Zn 6.3x45		PN-76/M-82001	2	2	2		
17	Nipple M6		PN-76/M-86002	2	2	2		



Fig. 18 Rear flap, complete

Compo	nent name			<b>_</b>		
	REA	R FLAP, COMPLETE		Quantity		
Drawin	ig No.	o. of complete component/part				
	18		6 XO		<b>V</b> 6	
No.	Part name	Drawing / standard No.	T66	T66	T66	
1	Rear flap	58RPN-04.01.000	1	1	1	
2	Fastening screw	29RPN-06.01.104	1	1	1	
3	Gate, cpl	29RPN-06.02.000	1	1	1	
4	Lever	29RPN-06.03.000	1	1	1	
5	String	29RPN-06.04.000	2	2	2	
6	Washer 21 Fe/Zn5	PN-78/M-82005	2	2	2	
7	Washer 13 Fe/Zn5	PN-78/M-82005	6	6	6	
8	Cotter pin S-Zn 5x28	PN-76/M-82001	2	2	2	
9	Cotter pin S-Zn 3.2x16	PN-76/M-82001	4	4	4	
10	Spring pin 3x10 Fe/Zn5	Pn-89/M-85023	1	1	1	
11	Triangle for slowly moving veh	cles	1⊗	1⊗	1⊗	

 $\otimes$  - special equipment, for order



Fig. 19 Set of superstructures

Compoi	nent name SET C		Quantity			
Drawin	g No. 19	No. of complete component/part 19			9 DK	V6
No.	Part name		Drawing / standard No.	T66	T66	T66
1	Superstructure, front 580		58RPN-10.01.000	1	1	1
2	Superstructure, side 580		58RPN-10.02.000	4	4	4
3	Superstructure, flap 580		58RPN-10.03.000	1	1	1
4	Side post 580		58RPN-10.04.000	2	2	2
5	Rear left post 580		58RPN-10.05.000	1	1	1
6	Rear right post 580		58RPN-10.06.000	1	1	1
7	Rear left section 580		58RPN-10.07.000	1	1	1
8	Rear right section 580		58RPN-10.08.000	1	1	1
9	Connection beam		58RPN-10.00.100	1	1	1
10	Superstructure bracket		58RPN-10.00.200	6	6	6
11	Superstructure ladder 580		58RPN-10.00.300	1	1	1
12	Screw M8x20-8.8-B/Fe5		PN-85/M-82105	72	72	72
13	Screw M10x16-8.8-B-Fe/Zn5		PN-85/M-82105	28	28	28
14	Nut M8-B-Fe/Zn5		PN-86/M-82144	8	8	8
15	Self-locking nut R M8-5-B-Fe	e/Zn5	PN-85/M-82175	4	4	4
16	Washer 8.4 Fe/Zn5		PN-78/M-82005	36	36	36
17	Spring washer Z8.2 Fe/Zn5		PN-77/M-82008	68	68	68
18	Spring washer Z10.2 Fe/Zn5		PN-77/M-82008	28	28	28
19	String, cpl.		58RPN-10.00.400	2	2	2
20	Screw M12x35-8.8-B-Fe/Zn5		PN-85/M-82105	2	2	2
21	Washer 13 Fe/Zn5		PN-78/M-82005	4	4	4
22	Spring washer Z12.2 Fe/Zn5		PN-77/M-82008	4	4	4
23	Nut M12-8-B-Fe/Zn5		PN-86/M-82144	6	6	6





Compo	mponent name							
	LADDER, SET					Quantity		
Drawin	g No.	No. of complete	e component/part					
	20		58RPN-00.01.000	6				
No.	Part name		Drawing / standard No.	T66	T66	T66		
1	Upper ladder		58RPN-00.01.100	1	1	1		
2	Lower ladder		58RPN-00.01.200	1	1	1		
3	Bolt, set		58RPN-00.01.300	1	1	1		
4	Stopper IK22		PPHU Plast Trading	4	4	4		
5	Screw M8x25-8.8-B-Fe/Zn5		PN-85/M-82105	4	4	4		
6	Nut M8-8-B-Fe/Zn5		PN-86/M-82144	4	4	4		
7	Washer 21 Fe/Zn5		PN-78/M-82005	1	1	1		
8	Spring washer Z8.2-Fe/Zn5		PN-90/M82008	4	4	4		
9	Washer 8.4-Fe/Zn5		PN-78/M-82005	4	4	4		
10	Cotter pin S-Zn 4x32		PN-76/M-82001	1	1	1		



Fig. 21 Chute, cpl.  $\otimes$ 

## $\otimes$ - for special order

Compor	nent name		Quantity		
Drawing No. 21		No. of complete component/part 58RPN-00.08.000		) DK	A
No.	Part name	Drawing / standard No.	T66	T66(	T66(
1	Chute	58RPN-00.08.001	1	1	1
2	Chute screw	58RPN-00.08.002	4	4	4
3	Pin S.3545		4	4	4
4	Rivet/nut M8, knurled		4	4	4
5	Washer 13 Fe/Zn5	PN-78/M-82005	4	4	4



Fig. 22 Undercarriage



Fig. 23 Undercarriage





Compo	nent name		Quantity			
<u> </u>		UNDERCA				, 
Drawin	g No.	No. of comp	blete component/part		×	
	22, 23, 24			6		V 6
No.	Part name		Drawing / standard No.	T66	T66!	T66!
1	Lower frame		58RPN-25.00.000	1	1	1
2	Hitch rod, cpl.		58RPN-02.00.000	-	-	1
3	Lighting beam, left		58RPN-00.12.100	1	1	1
4	Lighting beam, right		58RPN-00.12.200	1	1	1
5	Rotational hitch rod		58RPN-08.00.000	-	1	-
6	Rotational hitch rod		58RPN-08.00.000-PL	1	-	-
7	Buffer, set		58RPN-00.00.600	1	1	1
8	Bracket for hydraulic conduit	S	58RPN-17.00.000	1	1	1
9	Load crate support		58RPN-18.00.000	1	1	1
10	Load crate tilt bolt, cpl.		58RPN-00.05.000	2	2	2
11	Hitch rod fastening bolt		58RPN-00.06.000	2	2	2
12	Wing arm, cpl.		58RPN-00.11.000	2	2	2
13	Hitch rod suspension bolt		58RPN-00.00.001	1	1	1
14	Washer for hitch rod suspen	sion bolt	58RPN-00.00.002	2	2	2
15	Support bolt		29RPN-00.00.009	2	2	2
16	Space sleeve		58RPN-00.00.006	2	2	2
17	Shock-absorbing washer		64RPN-00.00.004	8	8	8
18	Wing I		58RPN-00.00.015	2	2	2
19	Wing II		58RPN-00.00.016	2⊗	2⊗	2⊗
20	Buffer bolt, cpl.		67RPN-00.06.00.00	2	2	2
21	String Art. 30904		DIN 11026	-	-	1
22	Rubber washer 180x180x10	0	7617/00-00-023	2	2	2
23	Wheel wedge	•	EB22-034	2	2	2
24	Wedge pocket		EB22-034	2	2	2
25	Automated catch			1⊗⊗	 1⊗⊗	 1⊗⊗
26	Nipple M8x1		PN-76/M-86002	2	2	2
27	Self-locking nut M10-5-B-Fe	/7n5	PN-85/M-82175	8	8	8
28	Nut M8-8-B-Fe/Zn5	2110	PN-86/M-82144	26	26	26
29	Sticker 25kN		58RPN-00 00 034	20	-	-
30	Self-locking put M16-8-B-Fe	/7n5	PN-85/M-82175	4	4	4
31	Round washer 10 5 Zn	2110	PN-59/M-82030	8	8	8
32	Washer 8 4-Fe/7n5		PN-78/M-82005	18	18	18
33	Washer 13 Fe/Zn5		PN-78/M-82005	4	4	4
34	Nipple M6		PN-76/M-86002	2	2	2
35	Washer 17 Fe/Zn5		PN-78/M-82005	2	2	2
36	Washer 21 Fe/Zn5		PN-78/M-82005	6	6	6
37	Spring washer 78 2 Fe/7n5		PN-90/M-82008	20	20	20
38	Spring washer 712 2 Fe/7n5		PN-90/M-82008	4	4	4
39	Spring washer z16 3 Fe/Zn5		PN-90/M-82008		-	6
40	Screw M8x25-8 8-B Fe/Zn		PN-85/M-82105	26	26	26
41	Screw M8x75-8 8-B Fe/7n		PN-85/M-82101	20	2	2
42	Screw M12x30-8 8-B Fe/7n		PN-85/M-82105	2	2	2
43	Screw M10x35-8 8-B-Fe/7n		PN-85/M-82105	8	8	8
44	Screw M8x16-8 8-B-Fe/7n5		DIN 7991	16	16	16
45	Screw M20x50-8 8-R-Fe/7n		PN-85/M-82105	2	2	2
46	Screw M16x50		PN-85/M-82105		-	6
47	Screw M16x80-5 8-R-Fe/7n		PN-85/M-82105	2	2	2
48	Cotter pin S-7n $4x^{32}$		PN-76/M-82001		<u> </u>	4
49	Cotter pin S-7n 6 3x45		PN-76/M-82001	2	2	2
			11110/11102001	2	-	-

Compo	nent name							
	UNDERCARRIAGE					Quantity		
Drawing No.		No. of complete	e component/part					
	22, 23, 24			0	T669 DK	A 9		
No.	Part name		Drawing / standard No.	TGG		T66		
50	Reflection triangle DOB31			2	2	2		
51	Screw M5x20-4.8-B-Fe/Zn5		PN-85/M-82215	4	4	4		
52	Nut M5-5-B-Fe/Zn5		PN-86/M-82144	4	4	4		
53	Washer Z5.1-Fe/Zn5		PN-77/M-82008	4	4	4		
54	Nut M20-8-B-Fe/Zn5		PN-86/M-82144	2	2	2		
55	Spring washer Z20-Fe/Zn5		PN-90/M-82008	2	2	2		
56	Rotational string, cpl. Art. 304	448		1	1	1		

## $\otimes$ - depending on used tyres

 $\otimes \otimes$  - for special order



Fig. 25 Two-conduit pneumatic brake system with ALB



Fig. 26 Two-conduit pneumatic brake system with ALB, continued



Fig. 27 Two-conduit pneumatic brake system with ALB, continued.

Compo	nent name		Quantity			
		UMATIC BR	AKE SYSTEM WITH ALB			
Drawin	ig No.	No. of complete	e component/part			
	25, 26, 27		67RPN-03.00.00.00	6	Í 6	<b>V</b> 6
No.	Part name		Drawing / standard No.	T66	T66	T66
1	Conduit BŁH W-W 5960		67RPN-03.01.00.00	1	1	1
2	Conduit BŁH W-W 5050		67RPN-03.02.00.00	1	1	1
3	Conduit BŁH W-W 4150		67RPN-03.03.00.00	1	1	1
4	Conduit BŁH W-W 2300		67RPN-03.04.00.00	1	1	1
5	Conduit BŁH W-W 1900		67RPN-03.05.00.00	1	1	1
6	Conduit BŁH W-W 1250		67RPN-03.06.00.00	1	1	1
7	Conduit BŁH W-W 450		67RPN-03.07.00.00	1	1	1
8	Conduit BŁH W-W 300		67RPN-03.08.00.00	1	1	1
9	Conduit BŁH W-W 210		67RPN-03.09.00.00	4	4	4
10	Rod		67RPN-03.00.00.02	1	1	1
11	Valve bracket, cpl.		67RPN-00.00.04.00	1	1	1
12	Air reservoir bracket		64RPN-15.00.100	2	2	2
13	Cylinder fork		58RPN-12.01.000	2	2	2
14	Air reservoir band		45RPN-00.13.000	2	2	2
15	Plug		29RPN-11.00.002	1	1	1
16	Bolt		29RPN-11.00.004	2	2	2
17	Cylinder 24" T25.24.000+shor	t fork, cpl.		2	2	2
18	Cylinder 24" T25.24.000, w/o f	ork		2	2	2
19	Three-way connector BŁH 0	63 309 066		5	5	5
20	Elbow connector BŁH 063 20	06 054		4	4	4
21	1 Straight connector BŁH M22x1.5/M16x1.5			4	4	4
22	2 Straight conn., long M22x1.5 063 130 047			4	4	4
23	3 Inspection connector 333 200 108			2	2	2
24	4 Sealing set KMPL M22x1.5			7	7	7
25	Spiral hose 12x1.5/4500/2xN	/l22x1.5/żółty	WS-8	1	1	1
26	Spiral hose 12x1.5/4500/2xM2	22x1.5/czer.	WS-7	1	1	1
27	Spring connector 86.10.014.	0		1	1	1
28	Air reservoir 585 000 000			1	1	1
29	Control valve 44.12.010.0			1	1	1
30	Braking force controller 61.2	0.015.0		1	1	1
31	Conduit connector 87.10.030	0.0		1	1	1
32	Conduit connector 87.15.030	0.0		1	1	1
33	Conduit connector 87.10.020	).0		1	1	1
34	Conduit connector 87.15.020	).0		1	1	1
35	Self-tapping screw Ø5.5x19		DIN-7504-K	11	11	11
36	Drain valve 83.10.012.0			1	1	1
37	Inspection connector 88.10.0	)11.0		1	1	1
38	Conduit filter 81.01.010.0			2	2	2
39	Band Ribenclip 16			13	13	13
40	Connector catch Art331000	)		2	2	2
41	Washer Cu 27/22/2			11	11	11
42	Washer Cu 22/17/2			6	6	6
43	Cotter pin S-Zn3.2x25	-	PN-76/M-82001	2	2	2
44	Screw M12x25 5.8-B-Fe/Zn5	) -	PN-85/M-82105	1		
45	Screw M10x35 5.8-B-Fe/Zn5	)	PN-85/M-82105	2	2	2
46	Screw M8x35 5.8-B-Fe/Zn5		MN-85/IVI-82105	6	6	6
4/	Screw INIX25 5.8-B-Fte/2n5		MN-85/IVI-82105	4	4	4
48	NUL WIZZX1.5-U5-B-Fe/ZN5		MIN-80/IVI-82153	4	4	4
49	INUT MITU-5-B-Fe/Zn5		μην-δρ/Ινι-δζ144	6	Ь	6

Compo	nent name TWO-CONDUIT PNE		Quantity			
Drawin	ng No.	No. of comple	te component/part			
	25, 26, 27		67RPN-03.00.00.00		Я	<b>V</b> 6
No.	Part name		Drawing / standard No.	T66	T66	T66
50	Nut M8-5-Fe/Zn5		PN-86/M-82144	8	8	8
51	Washer 13Fe/Zn5 Fe/Zn5		PN-78/M-82005	3	3	3
52	Washer 10.5 Fe/Zn5		PN-78/M-82005	2	2	2
53	Washer 8.4 Fe/Zn5		PN-78/M-82005	12	12	12
54	Spring washer Z12.2 Fe/Zn5		PN-77/M-82008	1	1	1
55	Spring washer Z10.2 Fe/Zn5		PN-77/M-82008	4	4	4
56	Spring washer Z8.2 Fe/Zn5		PN-77/M-82008	12	12	12
Sealin	ng set elements (pos. 24), (fo	or 1 set)				
57	Counter-nut M22x1.5			1	1	1
58	Ring 063.000.139			1	1	1
59	O-ring 93H			1	1	1
BŁH c	conduit elements (for 1 set)					
60	Conduit TEKALAN PA12 15>	(1.5 L= ⊗	DIN74324	1	1	1
61	Nut BŁH M22x1.5 063.000.0	)06		2	2	2
62	Cutting ring BŁH Ø15.2 063.0	0.005		2	2	2
63	Reinforcing sleeve Ø12x17			2	2	2

 $\otimes$  - Caution! While ordering a conduit give its length L (pos. 1 - 9)



Fig. 28 Tilt hydraulic system

Compor	nent name			• •••	
	TILT HYDRAU		Quantity		
Drawing	g No. No. of comp	plete component/part			
	28			¥	∢
No.	Part name	Drawing / standard No.	T669	T669	Т669 ,
1	Pipe I, set	58RPN-15.01.000	1	1	
2	Conduit DN13 H2.12 H4.13 2900	58RPN-15.02.000	1	-	
3	Conduit DN13 H2.12 H4.13 1500	58RPN-15.03.000	-	2	
4	Pipe II set	58RPN-14.01.000	-	1	
5	Conduit DN13 H2.12 H2.12 2500	45RPN-12.07.000	-	1	
6	Conduit DN13 H17.8H4.13 500	45RPN-12.06.000	1	1	
7	Conduit DN13 H17.8H2.12 800	45RPN-12.05.000	1	1	
8	Conduit DN13 H2.12 H4.13 650	53RPN-14.07.000	-	1	
9	Cylinder sleeve	58RPN-15.00.001	2	2	
10	Cable wheel	29RPN-13.00.001	1	1	
11	Wheel axle	29RPN-13.00.002	2	2	
12	Connector body	12RPN-18.00.002	1	1	
13	Quick-release connector – plug ZSR 12	.5 ZSR12-W06L	1	1	
14	Cap for plugs ISO 12.5		1	1	
15	Ball bearing 55 ŁK-S01-55/0.00		1	1	
16	Telescopic cylinder CT-S226-16-75/5/24	400CT-S226-75/0.00	1	1	
17	Cut-off valve Pister	HBKH-15L-DN13	1	1	
18	Three-way hydraulic valve	29RPN-13.00.003	-	1	
19	Thimble A6 Zn	PN-66/M-80247	1	1	
20	Bail clamp 6.5 oc	PN-73/M-80241	6	6	
21	Cable ∅6 6x19+P+p l=2520		1	1	
22	Heat-shrinkable pipe PBF 12/6 I=30	BN-89/C-89209	2	2	
23	Band RIBENCLIP 16		4	15	
24	Cotter pin S-Zn 4x32	PN-76/M-82001	4	4	
25	Washer Cu 27/22/2		1	1	
26	Self-tapping screw Ø5.5x19	DIN-7504-K	4	15	
27	Quick-release conn.– socket ZSR 12.5	ZSR12-G06L	-	1	
28	Screw M12x25-8.8-B-Fe/Zn5	DIN 7991	6	6	
29	Screw M12x110-8.8-B-Fe/Zn5	PN-85/M-82101	2	2	
30	Screw M6x45-5.8-B-Fe/Zn5	PN-85/M-82101	2	2	
31	Screw M6x50-5.8-B-Fe/Zn5	PN-85/M-82101	-	2	
32	Nut M6-5-B-Fe/Zn5	PN-86/M-82144	-	2	
33	Nut M5-5-B-Fe/Zn5	PN-86/M-82144	24	24	
34	Nut M12-5-B-Fe/Zn5	PN-86/M-82144	2	2	
35	Nut M22x1.5-0.4-B-Fe/Zn5	PN-86/M-82153	-	1	
36	Washer 17-Fe/Zn5	PN-78/M-82005	4	4	
37	Washer 6.4-Fe/Zn5	PN-78/M-82005	2	6	
38	Washer 6.1-Fe/Zn5	PN-77/M-82008	2	4	
39	Washer Z12.2-Fe/Zn5	PN-77/M-82008	2	2	



Fig. 29 Rear flap hydraulic system

Compo	nent name				<b>•</b> • • •		
REAR FLAP HYDRAULIC SYSTEM					Quantity		
Drawing No. No. of complete		e component/part					
29			6	Х Д	<b>V</b> 6		
No.	Part name		Drawing / standard No.	T66	TGG	T66	
1	Pipe I, set		67RPN-05.01.00.00	2	2	2	
2	Conduit DN13 H17.8 H4.13 8	300	58RPN-14.04.000	2	2	2	
3	Conduit DN13 H2.12 H4.13 7	700	58RPN-14.05.000	2	2	2	
4	Conduit DN13 H17.8 H4.13 1	300	58RPN014.06.000	2	2	2	
5	Conduit DN13 H2.12 H4.13 2900		58RPN-15.02.000	2	2	2	
6	Bolt		58RPN-14.00.001	2	2	2	
7	Connector body		12RPN-18.00.03	4	4	4	
8	Quick-release connector – pl	ug ZSR 12.5	ZSR12-W06L	2	2	2	
9	Cap for plugs ISO 12.5			2	2	2	
10	Cylinder 50sj36A/800m5b16		33RPN-04.07.00.00	2	2	2	
11	T-connector body 1613		PN-66/M-73147	2	2	2	
12	Band RIBENCLIP 16			24	24	24	
13	Self-tapping screw Ø5.5x19		DIN-7504-K	24	24	24	
14	Retaining spring ring Z30		PN-81/M-85111	2	2	2	
15	Washer 30 Fe/Zn5		PN-90/M-82004	2	2	2	
16	Cotter pin S-Zn 6.3x45		PN-76/M-82001	2	2	2	
17	Washer Cu 27/22/2			4	4	4	
18	Nipple M6		PN-76/M-86002	2	2	2	



Fig. 30 Support hydraulic system

Compo	nent name					•			
SUPPORT HYDRAULIC SYSTEM						Quantity			
Drawing No. No. of complete			te component/par	e component/part					
30		58RPI	58RPN-19.00.000 58RPN-13.00.000		6	9 DK	46		
No.	Part name		Drawing / standard No.		T66	T66	T66		
1	Support, cpl.		58RPN-00.02	.000		-	1		
2	Rotational hitch rod support, cpl.		58RPN-00.03	.000		1	-		
3	Conduit DN13 H2.12 H2.12 1800		58RPN-13.01	.000		1	1		
4	Conduit DN13 H17.8 H2.12 300		58RPN-13.02	.000		1	1		
5	Hydraulic valve		45RPN-26.00	.001		1	1		
6	Sticker "O/Z"		45RPN-26.00	.002		1	1		
7	Connector body		12RPN-18.00	.002		1	1		
8	Quick-release connector – plug ZSR12.5		ZSR12-W06L			1	1		
9	Cap for plugs ISO 12.5					1	1		
10	Screw M6x50-5.8-B-Fe/Zn5		PN-85/M-821	)1		2	2		
11	Washer Cu		27/22/2			1	1		
12	Washer Z6.1-Fe/Zn5		PN-77/M-820	08		2	2		
13	Nut M6-8-B-Fe/Zn5		PN-86/M-8214	14		2	2		



Fig. 31 Wiring system

Compo	nent name				0	_
		WIRING SY	(STEM		Quantity	/
Drawin	ig No.	No. of comple	ete component/part			
	31		58RPN-09.00.000		Т Д	46
No.	Part name	·	Drawing / standard No.	T66	TGG	T66
1	Central bundle		58RPN-11.01.00	1	1	1
2	Rear bundle		67RPN-10.01.00.00	1	1	1
3	Front bundle		58RPN-11.03.00	1	-	1
4	Front bundle		58RPN-11.04.00	-	1	1
5	Socket GN-7(X7)		8JB001941-002	2	2	2
6	Rear compact lamp WE 54P	1	04	1	1	1
7	Rear compact lamp WE 54L		03	1	1	1
8	Number plate lamp		LT120	2	2	2
9	Contour lamp		127 021 00 00	2	2	2
10	Front position light L0-110PF	כ		2	2	2
11	Side position light W17d		100Z	-	6	-
12	Screw M5x35-5.8 Fe/Zn5		PN/M82207	6	6	6
13	Screw M5x16 B Fe/Zn5		PN/M-82201	8	8	8
14	Spring washer 5.1 Fe/Zn9		PN/M-82008	4	4	4
15	Washer 5.3 Fe/Zn5		PN/M-82005	4	4	4
16	Nut M5-8-Fe/Zn5		PN/M-82144	4	4	4
17	Screw M5x25-B-5.8 Fe/Zn5		PN/M-82105	4	4	4
18	Self-tapping screw 5.5x19		DIN-7504-K	-	12	-
19	7-pole socket washer		006004.60	2	2	2
	Connection conductor		29RPN-10.05.00	1	1	1

s	Qty	
Front position light LO-110PP	C5W-SV 8.5	1
	P21W	1
Compact rear light, right (left)	P21/5W	1
	R5W	1
Number plate lamp LT-120	C5W-SV 8.5	1
Contour light, right (left)	R5W	1



Fig. 32 Parking brake

Compo	nent name				•			
PARKING BRAKE					Quantity			
Drawing No. No. of comple		lete component/part						
	32		58RPN-09.00.000		ND (	<b>A</b> 6		
No.	Part name		Drawing / standard No.	T66	T66(	T66(		
1	Parking brake lever		45RPN-22.01.000	2	2	2		
2	Brake gear		29RPN-12.01.000	1	1	1		
3	Brake bolt		45RPN-22.00.002	2	2	2		
4	Bolt		29RPN-12.00.001	1	1	1		
5	Cable catch		29RPN-01.00.018	3	3	3		
6	Cable wheel		29RPN-13.00.001	3	3	3		
7	Brake lock		31RPN-05.01.000	1	1	1		
8	Screw shackle S.2768		SPRAEX	2	2	2		
9	Thimble A6 Zn		PN-66/M-80247	4	4	4		
10	Bail clamp 6.5 Zn		PN-73/M-80241	12	12	12		
11	Cable I Ø6x19+P+p I=1900			1	1	1		
12	Cable II Ø6x19+P+p I=2300			1	1	1		
13	Washer 17 Fe/Zn5		PN-78/M-82005	5	5	5		
14	Washer 13 Fe/Zn5		PN-78/M-82005	4	4	4		
15	Cotter pin S-Zn 4x40		PN-76/M-82001	5	5	5		
16	Cotter pin S-Zn 3.2x25		PN76/M-82001	4	4	4		
17	Nut M5-5-B Fe/Zn5		PN-86/M-82144	24	24	24		
18	Heat-shrinkable pipe PBF 12	2/6 I=30	BN-89/C-89209	4	4	4		



Fig. 33 Brake gear

Compo	onent name				•			
BRAKE GEAR					Quantity			
Drawir	ng No.	No. of compl	ete component/part					
33			29RPN-12.01.000		ХO М	46		
No.	Part name	·	Drawing / standard No.	T66	T66	T66		
1	Crank, cpl.		29RPN-12.01.100	1	1	1		
2	String, cpl.		29RPN-12.01.200	1	1	1		
3	Screw, cpl.		29RPN-12.01.300	1	1	1		
4	Stopper, set		29RPN-12.01.400	1	1	1		
5	Body		29RPN-12.01.001	1	1	1		
6	Nut		29RPN-12.01.002	1	1	1		
7	Stopper		29RPN-12.01.003	1	1	1		
8	Spring		29RPN-12.01.004	1	1	1		
9	Sleeve		29RPN-12.01.005	1	1	1		
10	Washer 17 Fe/Zn5		PN-78/M-82005	1	1	1		
11	Washer 6.4 Fe/Zn5		PN-78/M-82005	1	1	1		
12	Crown nut K M16-5-C Fe/Zr	15	PN-86/M-82148	1	1	1		
13	Spring pin 6x24		PN-89/M-85023	1	1	1		
14	Nipple M6		PN-76/M-86002	1	1	1		
15	Cotter pin		PN-76/M-82001	1	1	1		


Fig. 34 Axle brake

Compo	nent name				<b>0</b>	_
		AXLE BRA	AKE		Quantity	/
Drawin	ving No. No. of complete component/part					
34				6	ХO AD	<b>V</b> 6
No.	Part name		Drawing / standard No.	T66	T66	TGG
1	Brake shoe		9FC412	2	2	2
2	Brake lining		9FCI406-GUARN	4	4	4
3	Cam shaft		LEWY 756S4N	1	1	1
4	Brake drum shield, set		910PP412 100	1	1	1
5	Spring		914M412/30	2	2	2
6	Stretcher		914SP262	1	1	1
7	Rubber shield		915C42	1	1	1
8	Special screw		906A10A	2	2	2
9	Special screw		906B10B	1	1	1
10	Special washer		915R10/21S	1	1	1
11	Bearing sleeve		921B42	2	2	2
12	Nipple		914INGR45	1	1	1
13	Sealing ring		921OR146	1	1	1
14	Self-locking nut		908DA10B	3	3	3
15	Outer retaining ring		914RES42	1	1	1
16	Rivet		930RIV	44	44	44
17	Outer retaining ring		915RES25	1	1	1
18	Brake lever		761W20004c0	1	1	1
19	Sleeve		921B38	1	1	1
20	Nipple		914INGR	1	1	1
21	Washer		915R08	1	1	1



Fig. 35 Hub / drum + axle bearings

Compo	nent name				<b>0</b>	_		
HUB / DRUM + AXLE BEARINGS					Quantity			
Drawin	ng No.	No. of com	plete component/part					
35					DK 0	<b>A</b> 6		
No.	Part na	me	Drawing / standard No.	T66	T66	T66		
1	Brake drum		66LV1050	1	1	1		
2	Hub		611L0125150170	1	1	1		
3	Bearing		902CC32217	1	1	1		
4	Bearing		902CC32214	1	1	1		
5	Crown nut M48x1.5		908DF48/65	1	1	1		
6	Сар		912T125AC	1	1	1		
7	Bearing shield		915N32217	1	1	1		
8	Bearing shield		915PA72	1	1	1		
9	Oil sealing		915PI150/87	1	1	1		
10	Seal		918G125	1	1	1		
11	Pin		903C22L1	10	10	10		
12	Screw M8x1.25		914VB8x10	6	6	6		
13	Nut M22x1.5		903D228G	10	10	10		
14	Spring washer		903RL22G	10	10	10		
15	Cotter pin		914C48E	1	1	1		



Fig. 36 Suspension

Compo	nent name				Quantity	,
		SUSPENS	SION		Quantity	
Drawing No. No. of comp		No. of comple	te component/part		K	
	36			6	Δ Δ	46
No.	Part name	•	Drawing / standard No.	T66	T66	T66(
1	Axle		58RPN-00.04.000	2	2	2
2	Parabolic suspension spring		67RPN-00.04.03.00	4	4	4
3	Left rocker, cpl.			1	1	1
4	Right rocker, cpl.		67RPN-00.04.01.00	1	1	1
5	Wheel, cpl 50x20 R22 32PR		58RPN-00.07.000-01	4	4	4
6	Wheel, cpl 550/60 R22.5 12PR ⊗		58RPN-00.07.000-02	4	4	4
7	Wheel, cpl 550/60 R22.5 16PR ⊗		58RPN-00.07.000-03	4	4	4
8	Wheel, cpl 385/65 R22.5 18PR ⊗		58RPN-00.07.000-04	4	4	4
9	Bail screw		58RPN-00.00.004	8	8	8
10	Upper suspension spring pla	te	58RPN-00.00.003	4	4	4
11	Nut M20x1.5-5-B-Fe/Zn5		PN-86/M-82144	32	32	32
12	Rocker bolt, cpl.		67RPN-00.04.02.00	2	2	2
13	Suspension spring bolt, cpl.		62RPN-00.00.300	4	4	4
14	Suspension spring bolt		45RPN-00.03.001	4	4	4
15	Washer		37RPN-18.00.002	2	2	2
16	Crown nut Z M24-8-B-Fe/Zn	5	PN-86/M-82148	4	4	4
17	Crown nut Z M36x3-8-B-Fe/Z	Zn5	PN-86/M-82148	2	2	2
18	Washer 25 Fe/Zn5		PN-78/M-82005	4	4	4
19	Washer 17 Fe/Zn5		PN-78/M-82005	8	8	8
20	Cotter pin S-Zn 6.3x71		PN-76/M-82001	2	2	2
21	Cotter pin S-Zn 5x50		PN-76/M-82001	4	4	4
22	Cotter pin S-Zn 4x32		PN-76/M-82001	8	8	8

 $\otimes$  - for special order

LIST OF DISC WHEELS AND TYRES				Quantity		
			60	69 DK	39 A	
No.	Part name	Drawing / standard No.	T6(	T6(	T6(	
	Wheel, cpl 50x20 R22 32PR	58RPN-00.07.000-01				
1	Disc wheel cpl 16.00x22	22.16.02	1	1	1	
2	Tyre Bridgestone 50x20.0R22 32 PR		1	1	1	
3	Air tube 16 x 22 w/valve TR 15		1	1	1	
4	Tyre flap 16.00x22		1	1	1	
	Wheel, cpl 550/60 R22.5 12PR	58RPN-00.07.000-02				
1	Disc wheel 16.00x22.5	225.16.01	1	1	1	
2	Tyre 550/60-22.5 12 PR		1	1	1	
3	Air tube 550/60-22.5 w/valve TR 15		1	1	1	
	Wheel, cpl 550/60 R22.5 16PR	58RPN-00.07.000-03				
1	Disc wheel 16.00x22.5		1	1	1	
2	Tyre 550/60-22.5 16 PR		1	1	1	
3	Air tube 550/60-22.5 w/valve TR 15		1	1	1	
	Wheel, cpl 385/65 R22.5 18PR	58RPN-00.07.000-04				
1	Disc wheel 11.75x22.5	225.1175.06	1	1	1	
2	Tyre reg. 385/65-22.5 18 PR		1	1	1	
3	Air tube 385/65-22.5 w/valve TR 15		1	1	1	

## NOTES