




SPARE PARTS CATALOGUE

MINI PYRUS






T6




T2



T5




T7




T8




T3




T4




T9



T10



T1







Table T1 – General view

General

Table T-1

Sin.	Name of part	Units	Material	Part number
1	Drive shield II	1		R00/21-000-010
2	Bolt I	2		R00/50-001-000
3	Band	2		R00/50-002-000
4	Protecting rubber	2		R00/50-003-000
5	Hydr. motor shield	1		R00/50-004-000
6	Drive shield I	1		R00/50-005-000
7	Complete frame	1		R01/50-000-000
8	Chassis	1		R02/50-000-000
9	Drive	1		R03/50-000-000
10	Hydr. system	1		R04/50-000-000
11	Conveyor sieve 650mm	1		R06/50-000-000
12	Complete share	1		R07/50-000-000
13	Complete right disc	1		R08/50-000-000
14	Support wheel	1		R13/50-000-000
15	Sorting table conveyor	1		R17/50-000-000
16	Bolt II	1		5-GSW02501050C
17	Curtain	1		mag
18	Rubber 5643/98-102/2	1		5-KOPBOLTAZA 1
19	Metal rope $\varnothing 6$ OC	1		3-NL I S06001
20	Clamp 2x20 B250-3.20/20	8		3-OB0B002020
21	Nut M10 TYP 48762(48/28)	2		3-PCVNKM10
22	Pin type R	3		6-ZAWLR42
23	Thread rod $\varnothing 10 \times 145$ OC	2		6-PRGW101000C
24	Screw M6x40-5.8B	12		PN-85/M-82101
25	Pad 6.4	12		PN-78/M-82005
26	Pad 6.4 big size	12		PN-78/M-82030
27	Spring pad Z 6.1	12		PN-77/M-82008
28	Nut M6-5-B	12		PN-86/M-82144
29	Screw M8x20-5.8B	4		PN-85/M-82101
30	Screw M8x50-5.8B	6		PN-85/M-82101
31	Screw M8x60-5.8B	2		PN-85/M-82101
32	Pad 8.4	12		PN-78/M-82005
33	Spring pad 8.2	12		PN-77/M-82008
34	Nut M8-5-B	2		PN-86/M-82144
35	Screw M10x35-5.8B	2		PN-85/M-82101
36	Pad 10.5	7		PN-78/M-82005
37	Nut M10-5-B	7		PN-86/M-82144



T2 – Complete frame

Complete frame


Table T-2

Sin	Name of part	Unit	Matter	Part number
1	Frame	1		R01/50-001-000
2	Complete turret	1		R01/50-002-000
3	Box handle	1		R01/50-003-000
4	Complete step	1		R01/50-004-000
5	Hinge	1		R01/50-006-000
6	Crossbar I	1		R01/50-007-000
7	Crossbar II	2		R01/50-008-000
8	Curtain handle	2		R01/50-009-000
9	Handle of adjustment box position	1		R01/50-010-000
10	Gain crossbar	4		R01/50-011-000
11	Distance plate	2		R01/50-012-000
12	Left stay	1		KRUKO R0150000002
13	Right stay	1		KRUKO R0150000001
14	Compl. left scraper 5644/21-013/1	1		2-MRC5644210130L
15	Compl. right scraper 5644/21-014/1	1		2-MRC5644210140P
16	Protecting shield 5644/21-040/0	6		2-MRC56442104000
17	Protecting shield II 5644/21-012/0	4		2-MRC56442101200
18	Roller with compl. rubber wheel 5644/21-017/16	6		2-MRC56442101710
19	Compl. epileptic shaker 5643/38-005/2	2		2-MRC56433800520
20	Roll PVCØ80 5223/00-009/0	4		2-MRC52230000900
21	Complete roller 5644/21-016/K L-40	2		2-MRC564421016K4
22	Complete back roller 5644/21-015/0	4		2-MRC56442101500
23	Screw M8x20-5.8B	4		PN-85/M-82101
24	Screw M8x30-5.8B	2		PN-85/M-82101
25	Locking screw M8x30-5.8B	4		PN-87/M-82406
26	Screw M8x35-5.8B	4		PN-85/M-82101
27	Screw M8x40-5.8B	1		PN-85/M-82101
28	Pad 8.4	25		PN-78/M-82005
29	Spring pad Z 8.2	15		PN-77/M-82008
30	Nut M8-5-B	15		PN-86/M-82144
31	Locking screw M10x30-5.8B	20		PN-87/M-82406
32	Screw M10x40-5.8B	4		PN-85/M-82101
33	Pad 10.5	28		PN-78/M-82005
34	Spring pad Z 10.2	24		PN-77/M-82008
35	Nut M10-5-B	24		PN-86/M-82144
36	Screw M12x35-5.8B	6		PN-85/M-82101
37	Screw M12x40-5.8B	12		PN-85/M-82101
38	Pad 13	28		PN-78/M-82005

Complete frame

Table T-2 next page

Sin	Part name	Unit	Matter	Part number
39	Spring pad Z 12.2	20		PN-77/M-82008
40	Nut M12-5-B	20		PN-86/M-82144
41	Spring pad Z 20.5	14		PN-77/M-82008
42	Nut M20-5-B	13		PN-86/M-82144
43	Low nut M20-5-B	1		PN-86/M-82153




T3 - Chassis

Chassis

Table T-3

Sin	Part name	Units	Matter	Part number
1	Right half axle	1		R02/50-002-001
2	Complete axle	1		R02/50-003-000
3	Compl. halfaxle R01.08.001.040K	20		2-MRCKP010800104
4	Right half ring 5.00-9	2		2-MRCKP00500090P
5	Left half ring 5.00-9	2		2-MRCKP00500090L
6	Tire 5.00-9/4	2		2-MRCK0050000900
7	Tube 5.00-9	2		2-MRCKD050000900
8	Screw M8x20-5.8B	16		PN-85/M-82101
9	Pad 8,4	16		PN-78/M-82005
10	Spring pad Z 8,2	16		PN-77/M-82008
11	Nut M8-5-B	16		PN-86/M-82144
12	Screw M10x30-5.8B	4		PN-85/M-82101
13	Pad 10,5	4		PN-78/M-82005
14	Spring pad Z 10,2	4		PN-77/M-82008
15	Nut M10-5-B	4		PN-86/M-82144
16	Screw M12x25-5.8B	4		PN-85/M-82101
17	Screw M12x35-5.8B	8		PN-85/M-82101
18	Pad 13	8		PN-78/M-82005
19	Spring pad Z 12,2	8		PN-77/M-82008
20	Nut M12-5-B	8		PN-86/M-82144



T4 - Drive

Drive system


Table T-4

Sin	Part name	Units	Matters	Part number
1	Input shaft	1		R03/50-001-000
2	Upper sieve shaft	1		R03/50-002-000
3	Back sieve shaft	1		R03/50-003-000
4	Main lower shaft	1		R03/50-004-000
5	Bushing	1		R03/50-005-000
6	Safety pad	1		R03/50-006-000
7	Chain wheel Z28 5/8" Ø35	1		2-MRCKŁZ2858350
8	Chain wheel Z 12-3/4" Ø25-rolled	1		2-MRCRKŁZ123400
9	Chain wheel Z 12-3/4" Ø25 L-42	1		2-MRCRKŁZ123400
10	Chain wheel Z15 5/8" Ø35	1		2-MRCRKŁZ1558350
11	Planceta UCF207	4		2-MRCŁOŻUCF207
12	Planceta UCFL205	2		2-MRCŁOŻUCFL205
13	Planceta UCP206	1		2-MRCŁOŻUCP206
14	Planceta UCPA207	1		2-MRCŁOŻUCPA207
15	Large bevel wheel	1		2-MRC56453001600
16	Small bevel wheel	1		2-MRC56443000400
17	Compl. drive wheel 5643/38-002/1	2		2-MRC56433800210
18	Compl. drive wheel 5644/60-005/5	2		2-MRC56446000500
19	Galla's chain R-1 3/4" 10-92 ogniwa	1		2-MRCŁAGALR10340
20	Galla's chain R-1 3/4" 12-30 ogniwa	1		2-MRCŁAGALR10340
21	Plastyk roll 5223/00-009/0	2		2-MRC52230000900
22	Shaft shield 4DR	1		2-MRCROSLWAŁPW01
23	Spring pin 8x50	2		6-KOŁSP08050
24	Parallel key A8x7x25	1		PN-70/M-85005
25	Parallel key A8x7x30	1		PN-70/M-85005
26	Parallel key A10x8x30	3		PN-70/M-85005
27	Parallel key A10x8x60	2		PN-70/M-85005
28	Edging ring Z25	2		PN-81/M-85111
29	Edging ring Z28	1		PN-81/M-85111
30	Edging ring Z35	3		PN-81/M-85111
31	Screw M8x20-5.8B	4		PN-85/M-82101
32	Screw M8x25-8.8B	1		PN-85/M-82101
33	Screw M8x30-8.8B	2		PN-85/M-82101
34	Pad 8.4	8		PN-78/M-82005
35	Spring pad Z 8.2	4		PN-77/M-82008
36	Nut M8-5-B	6		PN-86/M-82144
37	Lock screw M12x40 82406 0C Fe/Zn	16		6-SM4612040C
38	Lock screw M12x45 82406 0C Fe/Zn	6		6-SM4612045C

Drive system


Table T-4 next page

S/n	Part name	Units	Matter	Part number
39	Screw M12x45-5.8B	2		PN-85/M-82101
40	Screw M12x65-5.8B	2		PN-85/M-82101
41	Pad 13	28		PN-78/M-82005
42	Spring pad Z 12.2	26		PN-77/M-82008
43	Nut M12-5-B	26		PN-86/M-82144
44	Screw M14x30-5.8B	2		PN-85/M-82101
45	Screw M14x40-5.8B	2		PN-85/M-82101
46	Pad 15	4		PN-78/M-82005
47	Spring pad Z 14.2	4		PN-77/M-82008
48	Nut M14-5-B	4		PN-86/M-82144



T4 – Option with full hydraulic

Sin	Part name	Units	Matter	Part number
1	Sieve lower drive shaft	1		RH03/50-004-000
2	Compl. box	1		R03/55-003-000
3	Plate I	1		KRUK0 R0355003001
4	Shield	1		KRUK0 R0355003006
5	Hydraulic motor EPRM 200C	1		2-MRCHYSIEPRM200
6	Chain wheel Z 12-3/4" Ø25 L-42	1		2-MRCRKŁZ123400
7	Chain wheel Z 12-3/4" Ø30 L-44	1		2-MRCRKŁZ1234002
8	Chain wheel Z15 5/8" Ø35	1		2-MRCRKŁZ1558350
9	Chain wheel Z28 5/8" Ø35	1		2-MRCRKŁZ2858350
10	Chain wheel Z 46-5/8" Ø25-L-35	1		2-MRCRKŁZ4658001
11	Galla's chain R-2-3/4" B-2	1		2-MRCŁAGALR20340
12	Chain clamp R-2-3/4" 12B-2	1		2-MRCŁAGASR20340
13	Galla's chain R-1-5/8" B-1	1		2-MRCŁAGALR10580
14	Parallel key A 8x7x25	1		PN-70/M-85005
15	Parallel key A 10x8x40	1		PN-70/M-85005
16	Screw M6x20-5.8B	4		PN-85/M-82101
17	Spring pad Z 6.1	4		PN-77/M-82008
18	Screw M8x30-5.8B	2		PN-85/M-82101
19	Nut M8-5-B	2		PN-86/M-82144
20	Lock screw M12x40-5.8B	2		PN-87/M-82406
21	Screw M12x25-5.8B	4		PN-85/M-82101
22	Spring pad Z 12.2	6		PN-77/M-82008
23	NutM12-5-B	2		PN-86/M-82144




T4.2 – Option with mechanical drive

Sin	Part name	Units	Matter	Part number
1	Input shaft	1		R03/50-001-000
2	Upper sieve shaft	1		R03/50-002-000
3	Back sieve shaft	1		R03/50-003-000
4	Main lower shaft	1		R03/50-004-000
5	Bushing	1		R03/50-005-000
6	Safety pad	1		R03/50-006-000
7	Chain wheel Z28 5/8" Ø35	1		2-MRCKŁZ2858350
8	Chain wheel Z 46-5/8" Ø25-L-35	1		2-MRCRKŁZ4658001
9	Chain wheel Z 12-3/4" Ø25 L-42	1		2-MRCRKŁZ123400
10	Chain wheel Z15 5/8" Ø35	1		2-MRCRKŁZ1558350
11	Planceta UCF207	4		2-MRCŁOŻUCF207
12	Planceta UCFL205	2		2-MRCŁOŻUCFL205
13	Planceta UCP206	1		2-MRCŁOŻUCP206
14	Planceta UCPA207	1		2-MRCŁOŻUCPA207
15	Large bevel wheel	1		2-MRC56453001600
16	Small bevel wheel	1		2-MRC56443000400
17	Compl. drive wheel 5643/38-002/1	2		2-MRC56433800210
18	Compl. drive wheel 5644/60-005/5	2		2-MRC56446000500
19	Galla's chain R-1 5/8" 10-92 ogniwa	1		2-MRCŁAGALR10580
20	Galla's chain R-1 3/4" 12-30 ogniwa	1		2-MRCŁAGALR10340
21	Plastyk roller 5223/00-009/0	2		2-MRC52230000900
22	Shaft shield 4DR	1		2-MRCROSLWAŁPW01
23	Spring pin 8x50	2		6-KOŁSP08050
24	Parallel key A8x7x25	1		PN-70/M-85005
25	Parallel key A8x7x30	1		PN-70/M-85005
26	Parallel key A10x8x30	3		PN-70/M-85005
27	Parallel key A10x8x60	2		PN-70/M-85005
28	Edging ring Z25	2		PN-81/M-85111
29	Edging ring Z28	1		PN-81/M-85111
30	Edging ring Z35	3		PN-81/M-85111
31	Screw M8x20-5.8B	4		PN-85/M-82101
32	Screw M8x25-8.8B	1		PN-85/M-82101
33	Screw M8x30-8.8B	2		PN-85/M-82101
34	Pad 8.4	8		PN-78/M-82005
35	Spring pad Z 8.2	4		PN-77/M-82008
36	Nut M8-5-B	6		PN-86/M-82144
37	Lock screw M12x40 82406 0C Fe/Zn	16		6-SM4612040C
38	Lock screw M12x45 82406 0C Fe/Zn	6		6-SM4612045C

Option with mechanical drive

Table T-4/2 next page

S/n	Part name	Units	Matter	Part number
39	Screw M12x45-5.8B	2		PN-85/M-82101
40	Screw M12x65-5.8B	2		PN-85/M-82101
41	Pad 13	28		PN-78/M-82005
42	Spring pad Z 12.2	26		PN-77/M-82008
43	Nut M12-5-B	26		PN-86/M-82144
44	Screw M14x30-5.8B	2		PN-85/M-82101
45	Screw M14x40-5.8B	2		PN-85/M-82101
46	Pad 15	4		PN-78/M-82005
47	Spring pad Z 14.2	4		PN-77/M-82008
48	NutM14-5-B	4		PN-86/M-82144




T5 – Hydraulic system

Hydraulic system

Table T-5

Sin	Part name	Units	Matter	Part number
1	Hydraulic motor EPRM 200C	1		2-MRCHYSIEPRM200
2	Overflow adjustent RP1610/216 (Opcja II)	1		2-MRCRREGPRZ0001
3	Conector simple body 18x1.5 / M22x1.5	2		3-HYDKPP018
4	Seal CU 22	2		6-UMCU022
5	Elbow K12-10 M18x1.5	2		3-HYDKOL011
6	Tip K1-10 M18/1.5	2		3-HYDKON010
7	Bush T-10	4		3-HYDTUZ002
8	Plug M18*1.5EURO	2		3-HYDRRWSS18015
9	Plug cup EURO	2		3-PVCZWTEUR001
10	Hydraulic hose 10/1 3/8"-2 szl.	4m		3-HYDWAH001
11	Parallel key A8x25	1		PN-70/M85005
12	Screw M8x40 5.8 0C	4		PN-85/M-82302
13	Spring pad Z 8.2	4		PN-77/M-82008




T6 – Conveyor sieve

Conveyor sieve

Table T-6

Sin	Part name	Units	Matter	Part number
1	Sieve rod I	69		R06/50-002-000
2	Sieve rod II	2		R06/50-003-000
3	Connecting rod	1		R06/50-005-000
4	Connecting rod covering	1		R06/50-007-000
5	Rod with tips 5643/58-061/ONT	18		2-MRC56435806100
6	Covering 15/24	71		2-MRCOT024015001
7	Sieve side belt	2		2-MRCRPZTPW3EP44
8	Large right side halflock	1		2-MRC56443600300P
9	Large left side halflock	1		2-MRC56443600300L
10	Large left middle halflock	1		2-MRC56443600301L
11	Large right middle halflock	1		2-MRC56443600301P
12	Sieve nut 5613/09-051/0	174		2-MRC54130905100
13	Sieve nut 5644/38-006/0	8		2-MRC56443800600
14	Steeple-head rivet 5x18-C Fe/Zn	348		2-MRCNISTP05014C
15	Screw M5x25 82105	8		DIN 7991
16	Screw M5x30 82105	8		DIN 7991
17	Nut M5-5-B	16		PN-86/M-82144




T7 – Complete share

Complete share

Table T-7

Sin	Part name	Units	Matter	Part number
1	Rod	3		R07/50-000-010
2	Share	1		R07/50-001-000
3	Complete blade	6		R07/50-002-000
4	Middle share	1		R07/50-003-000
5	Left share	1		R07/50-004-000
6	Right share	1		R07/50-005-000
7	Screw M12x30-8.8-B	9		PN-87/M-82402
8	Spring pad Z 12.2	9		PN-77/M-82008
9	Nut M12-5-B	9		PN-86/M-82144




T8 – Complete right couler

Complete right coulter

Table T-8

Sin	Part name	Units	Matter	Part number
1	Mounting coulter hub	1		KRUKO R0850001002
2	Coulter handle	1		KRUKO R0850001000
3	shield coulter 400x85	1		2-MRCRKRT4008500
4	Coulter hub L-60 M24 Kpl.	1		2-MRCRPIKL60M240
5	Locking screw M12x40-8.8B	4		PN-87/M-82406
6	Pad 13	4		PN-78/M-82005
7	Spring pad Z 12.2	4		PN-77/M-82008
8	Nut M12-5-B	4		PN-86/M-82144
9	Screw M16x60-8.8B	2		PN-85/M-82101
10	Pad 17	2		PN-78/M-82005
11	Spring pad Z 16.3	2		PN-77/M-82008
12	Nut M16-5-B	1		PN-86/M-82144
13	Self secure nut M16-5-B	1		PN-86/M-82175
14	Pad 25	1		PN-78/M-82005
15	Spring pad Z 24.5	1		PN-77/M-82008
16	Nut M24-5-B	1		PN-86/M-82144




T9 – Support wheel

Support wheel

Table T-9

S/n	Part name	Units	Matter	Part number
1	Bolt	1		R13/50-000-001
2	Hub (3 holes)	1		2-MRC52110003200
3	Planceta 6205 2RS	2		2-MRCŁOŽ62052RS
4	Sealing ring A 25x52x10DW	1		6-UTPIA02505210DW
5	Seeger ring 55 W	1		6-PISE055W
6	seeger ring 25 Z	1		6-PISE025Z
7	Right half hoop 400x8	1		2-MRCKP00400080P
8	Left half hoop 400x8	1		2-MRCKP00400080L
9	Tube 400x8	1		2-MRCKD040000800
10	Tire 400x8	1		3-KOL0040008
11	Screw M12x35-5.8B	3		PN-85/M-82101
12	Pad 13	3		PN-78/M-82005
13	Spring pad Z 12.2	3		PN-77/M-82008
14	Nut M12-5-B	3		PN-86/M-82144
15	Screw M8x20-5.8B	3		PN-85/M-82101
16	Pad 8.4	6		PN-78/M-82005
17	Spring pad Z 8.2	3		PN-77/M-82008
18	Nut M8-5-B	3		PN-86/M-82144



T10 – Sorting table conveyor

Sorting table conveyor

Table T-10

S/n	Part name	Units	Matter	Part number
1	Sieve rod	75		R17/50-002-000
2	Connenting rod	1		R17/50-004-000
3	Anti rock part	2		R17/50-05-000
4	Sieve belt	2		2-MRCRPGTG3EP500
5	Covering	76		2-MRCOT018012001
6	Small side half hinge M2	2		2-MRC56443800810
7	Small middle half hinge M2	2		2-MRC56443800710
8	Sieve nut	12		2-MRC54130905100
9	Rivet 5x14-C Fe/Zn	276		2-MRCNISTP05014C
10	Rivet. 5x22-C Fe/Zn	8		2-MRCNISTP05022C
11	Screw M5x25 82105	8		6-SJ1508025C
12	Nut M5-5-B	8		PN-86/M-82144

MINI PYRUS PART INDEX

Symbol KTM	Part name	Table	Pos. in tabl.	Units
1	2	3	4	5
	Curtain	1	17	1
KRUKO R0150000002	Left stay	2	12	1
KRUKO R0150000001	right stay	2	13	1
KRUKO R0355003001	Plate I	4/1	3	1
KRUKO R0355003006	Shield	4/1	4	1
KRUKO R0850001002	coulter hub mounting	8	1	1
KRUKO R0850001000	coulter handle	8	2	1
RH03/50-004-000	Sieve shaft-Lower drive	4/1	1	1
R00/21-000-010	Drive shield II	1	1	1
R00/50-001-000	Bolt I	1	2	2
R00/50-002-000	Band	1	3	2
R00/50-003-000	Protecting rubber	1	4	2
R00/50-004-000	Hydr. motor shield	1	5	1
R00/50-005-000	Drive shield I	1	6	1
R01/50-000-000	Complete shield	1	7	1
R01/50-001-000	Frame	2	1	1
R01/50-002-000	Compl. turret	2	2	1
R01/50-003-000	Box handle	2	3	1
R01/50-004-000	Compl. step	2	4	1
R01/50-006-000	Hinge	2	5	1
R01/50-007-000	Crossbar I	2	6	1
R01/50-008-000	Crossbar II	2	7	2
R01/50-009-000	Curtain handle	2	8	2
R01/50-010-000	Adjust. of box position handle	2	9	1
R01/50-011-000	Crossbar	2	10	4
R01/50-012-000	Spacer plate	2	11	2
R02/50-000-000	Chassis	1	8	1
R02/50-002-001	Right half axle	3	1	1
R02/50-003-000	Complete axle	3	2	1
R03/50-000-000	Drive	1	9	1
R03/50-001-000	Input shaft	4	1	1
R03/50-002-000	Upper sieve shaft	4	2	1
R03/50-003-000	Back sieve shaft	4	3	1
R03/50-004-000	Main lower shaft	4	4	1
R03/50-005-000	Bush	4	5	1
R03/50-006-000	Protecting pad	4	6	1

MINI PYRUS PART INDEX

[illegible]

