


**DIGGER TO ROOT  
Z 653**

**SPARE PARTS CATALOQUE**



## LIST OF TABLES





TABLE 1

**LIST OF TABLES**

| <b>Sin.</b> | <b>Name of table</b>         | <b>Number of table</b> |
|-------------|------------------------------|------------------------|
| <b>1.</b>   | <b>List of tables</b>        | <b>Table-1</b>         |
| <b>2.</b>   | <b>Complete frame</b>        | <b>Table-2</b>         |
| <b>3.</b>   | <b>The propulsion system</b> | <b>Table-3</b>         |
| <b>4.</b>   | <b>Sifter</b>                | <b>Table-4</b>         |
| <b>5.</b>   | <b>Chassis</b>               | <b>Table-5</b>         |
| <b>6.</b>   | <b>Belts of sifter</b>       | <b>Table-6</b>         |
| <b>7.</b>   | <b>Coulter</b>               | <b>Table-7</b>         |
| <b>8.</b>   | <b>Electrical system</b>     | <b>Table-8</b>         |
| <b>9.</b>   | <b>Blade</b>                 | <b>Table-9</b>         |



## Complete frame

Table-2

| <i>Sin.</i> | <i>Name of part</i>  | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Notes</i> |
|-------------|----------------------|--------------------------------------|------------------------|--------------|
| 1           | Frame                | R01/07-000-000                       | 1                      |              |
| 2           | Shute                | R10/07-000-000                       | 2                      |              |
| 3           | Tensioner            | R00/07-001-000                       | 2                      |              |
| 4           | Bracket              | R01/07-003-000                       | 1                      |              |
| 5           | Crossbar             | R01/07-002-000                       | 1                      |              |
| 6           | Tensioner frame      | R00/07-001-001                       | 1                      |              |
| 7           | Plate of peak        | R01/07-000-003                       | 2                      |              |
| 8           | Peak                 | R01/07-000-003                       | 2                      |              |
| 9           | Right cover of drive | Laminate                             | 1                      |              |
| 10          | Left cover of drive  | Laminate                             | 1                      |              |
| 11          | Axle of roll         | RP06/07-004-001                      | 1                      |              |
| 12          | Axle of return roll  | RP06/07-001-001                      | 1                      |              |
| 13          | Cover II             | RP06/07-007-003                      | 1                      |              |
| 14          | Ring Z 17            | PN-81/M-85111                        | 1                      |              |
| 15          | Axle of sifter roll  | RP06/07-005-001                      | 1                      |              |
| 16          | Corps of sifter oll  | RP06/07-005-002                      | 1                      |              |
| 17          | Cover I              | RP06/07-004-003                      | 1                      |              |
| 18          | Shield               | 2-09-544-210400                      | 4                      |              |
| 19          | Grommet .A30x72x10   | PN-72/M-86964                        | 1                      |              |
| 20          | Planceta 6206        | PN-81/M-85111                        | 2                      |              |
| 21          | Corps of return roll | RP06/07-007-002                      | 1                      |              |
| 22          | Ring W 35            | PN-81/M-85111                        | 1                      |              |
| 23          | Spacer sleeve        | RP06/07-005-003                      | 1                      |              |
| 24          | Planceta 6003        | PN-81/M-85111                        | 4                      |              |
| 25          | Ring A20x37x7        | PN-72/M-86964                        | 1                      |              |
| 26          | Corps of roll        | RP06/07-004-002                      | 1                      |              |
| 27          | Sifter roll II       | RP06/07-005-000                      | 4                      |              |
| 28          | Return roll          | RP06/07-007-000                      | 4                      |              |
| 29          | Sifter roll I        | RP06/07-004-000                      | 4                      |              |
| 30          | Spring               | 2-09-609-000023                      | 2                      |              |
| 31          | Pad 23               | PN-78/M-82005                        | 4                      |              |
| 32          | Washer spring 23.5   | PN-77/M-82008                        | 4                      |              |
| 33          | Nut 22               | PN-86/M-82144                        | 4                      |              |
| 34          | Pad 21               | PN-78/M-82005                        | 8                      |              |
| 35          | Washer spring 20.5   | PN-77/M-82008                        | 8                      |              |
| 36          | Nut 20               | PN-86/M-82144                        | 8                      |              |

The propulsion system




Table 3

**THE PROPULSION SYSTEM**

| <b>Sin.</b> | <b>Name of tables</b>      | <b>Number of table</b> |
|-------------|----------------------------|------------------------|
| <b>1.</b>   | <b>Complete roller I</b>   | <b>Table-3.1</b>       |
| <b>2.</b>   | <b>Complete roller II</b>  | <b>Table-3.2</b>       |
| <b>3.</b>   | <b>Complete roller III</b> | <b>Table-3.3</b>       |
| <b>4.</b>   | <b>Tensioner I</b>         | <b>Table-3.4</b>       |
| <b>5.</b>   | <b>Tensioner II</b>        | <b>Table-3.5</b>       |

# COMPLETE ROLLER 1




TABLE 3.1




## Complete roller I

Table-3.1

| <i>Sin.</i> | <i>Name of part</i>    | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|------------------------|--------------------------------------|------------------------|-------------|
| 1           | Roller                 | R03/07-000-001                       | 1                      |             |
| 2           | Pulley III             | R03/07-006-000                       | 1                      |             |
| 3           | Bushing                | R03/07-000-002                       | 1                      |             |
| 4           | Handle of chain I      | R03/01-003-000                       | 1                      |             |
| 5           | Handle of chain II     | R03/01-004-000                       | 1                      |             |
| 6           | Cover I                | Laminat                              | 1                      |             |
| 7           | Cover II               | Laminat                              | 1                      |             |
| 8           | Binding P-206          | 2-09-1400-131-8                      | 2                      |             |
| 9           | Clutch                 | 2-05-644-300256                      | 1                      |             |
| 10          | Miter gear             | 2-09-1400-131-8                      | 1                      |             |
| 11          | Half pin 5/8-2-10B     | 2-08-047-003-4                       | 1                      |             |
| 12          | Circlip 30             | PN-72/M-85101                        | 1                      |             |
| 13          | ESP circlip Z30        | PN-81/N-85111                        | 3                      |             |
| 14          | V-belt C2360           | PN-86/M-85200/06                     | 1                      |             |
| 15          | Neck bolt M10x25 Fe/Zn | PN-73/M-82406                        | 10                     |             |
| 16          | Pad 8,4                | PN-78/M-82005                        | 6                      |             |
| 17          | Nut M10-5-B Fe/Zn      | PN-86/M-82144                        | 10                     |             |
| 18          | Screw M8x25.6-B Fe/Zn  | PN-85/M-82101                        | 6                      |             |
| 19          | Chain 108-2-17         | PN-77/M-84168                        |                        |             |
| 20          | Drain prism. A 8x7x36  | PN-70/M-85005                        | 3                      |             |
| 21          | Planceta FD-206        | PN-73/M-86120                        | 1                      |             |

## COMPLETE ROLLER 2



**TABLE 3.2**

## Complete roller II

Table-3.2

| <i>Sin.</i> | <i>Name of part</i>    | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|------------------------|--------------------------------------|------------------------|-------------|
| 1           | Shaft of sifter        | R03/07-001-001                       | 1                      |             |
| 2           | Drive wheel            | R06/01-007-002                       | 2                      |             |
| 3           | Bush I                 | R03/07-001-002                       | 2                      |             |
| 4           | Hub                    | R06/01-007-005                       | 1                      |             |
| 5           | Pulley I               | R03/07-004-000                       | 2                      |             |
| 6           | Pulley II              | R03/07-005-000                       | 1                      |             |
| 7           | Shield 5643/38-004/0   | 2-09-643-380-040                     | 1                      |             |
| 8           | Cover P-207            | 2-09-1400-131-8                      | 6                      |             |
| 9           | Parallel key A10x8x50  | PN-70/M-85005                        | 2                      |             |
| 10          | Planceta FD 207        | PN-73/M-86120                        | 2                      |             |
| 11          | Neck bolt M10x25 Fe/Zn | PN-73/M-82402                        | 6                      |             |
| 12          | Nut M10-5-B            | PN-86/M-82144                        | 16                     |             |
| 13          | Pad 10,5               | PN-78/M-82005                        | 34                     |             |
| 14          | Screw M8x30 Fe./Zn     | PN-85/M-82101                        | 2                      |             |
| 15          | Nut M8-5-B             | PN-86/M-82144                        | 2                      |             |
| 16          | Screw M10x40           | PN-85/M-82101                        | 12                     |             |
| 17          | Screw M10x45           | PN-85/M82101                         | 2                      |             |
| 18          | Parallel key A8x7x36   | PN-70/M-85005                        | 3                      |             |
| 19          | ESP cir clip Z30       | PN-81/M-85111                        | 3                      |             |

COMPLETE ROLLER 3




TABLE 3.3

## Complete roller III

Table-3.3

| <i>Sin.</i> | <i>Name of part</i>      | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|--------------------------|--------------------------------------|------------------------|-------------|
| 1           | Shaft of sifter          | R03/07-002-001                       | 1                      |             |
| 2           | Drive wheel              | R06/01-007-002                       | 2                      |             |
| 3           | Bush I                   | R03/07-001-002                       | 2                      |             |
| 4           | Hub                      | R06/01-007-005                       | 1                      |             |
| 5           | Pulley I                 | R03/07-004-000                       | 1                      |             |
| 6           | Shield 5643/38-004-0     | 2-09-643-380-040                     | 1                      |             |
| 7           | Cover P-207              | 2-09-1400-131-8                      | 6                      |             |
| 8           | ESP cir clip A10x8x50    | PMN-70/M-85005                       | 2                      |             |
| 9           | Planceta FD 206          | PN-73/M-86120                        | 2                      |             |
| 10          | Neck bolt M10x25 Fe/Zn   | PN-73/M-82402                        | 6                      |             |
| 11          | Nut M10-5-B              | PN-86/M-82144                        | 16                     |             |
| 12          | Pad 10,5                 | PN-86/M-82005                        | 34                     |             |
| 13          | Screw M10x40             | PN-85/M-82101                        | 12                     |             |
| 14          | Screw M10x45-B 8-B Fe/Zn | PN-85/M-82101                        | 2                      |             |
| 15          | ESP cir clip A 8x7x36    | PN-70/M-85005                        | 3                      |             |
| 16          | Parallel key Z30         | PN-81/M-85111                        | 2                      |             |
| 17          | V-belt C2360             | PN-86/M-85200/06                     | 1                      |             |

# TENSIONER 1




TABLE 3.4

## Tensioner I

Table-3.4

| <i>Sin.</i> | <i>Name of part</i> | <i>Symbol KTM or<br/>standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|---------------------|------------------------------------------|------------------------|-------------|
| 1           | Roll                | R03/01-006-001                           | 1                      |             |
| 2           | Shaft               | R03/07-007-001                           | 1                      |             |
| 3           | Bush                | R03/01-006-003                           | 1                      |             |
| 4           | Handle              | R03/07-010-000                           | 1                      |             |
| 5           | Neck bolt W47       | PN-81/M-85111                            | 2                      |             |
| 6           | Planceta 6005       | PN-85/M-86100                            | 2                      |             |
| 7           | Nut M16             | PN-86/M-82144                            | 1                      |             |
| 8           | Pad 17              | PN-77/M-82005                            | 1                      |             |
| 9           | Grease M10          | PN-76/M-86007                            | 1                      |             |

TENSIONER 2




TABLE 3.5



## Tensioner II

Table-3.5

| <i>Sin.</i> | <i>Name of part</i> | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|---------------------|--------------------------------------|------------------------|-------------|
| 1           | Axle                | R03/07-003-001                       | 1                      |             |
| 2           | Bush                | R03/07-003-002                       | 1                      |             |
| 3           | Handle              | R03/07-009-000                       | 1                      |             |
| 4           | Roll                | 2-09-644-51-08-90                    | 1                      |             |
| 5           | Planceta 6004       | PN-85/M-86100                        | 1                      |             |
| 6           | Neck bolt W42       | PN-81/M-85111                        | 1                      |             |
| 7           | Pad 17              | PN-77/M-82005                        | 1                      |             |
| 8           | Nut M16             | PN-86/M-82144                        | 1                      |             |

# SIFTER




TABLE 4

## Sifter

Table-4

| <i>Sin.</i> | <i>Name of part</i> | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>note</i> |
|-------------|---------------------|--------------------------------------|------------------------|-------------|
| 1           | Shaft of sifter     | R14/07-001-000                       | 1                      |             |
| 2           | Cover               | R14/07-003-000                       | 1                      |             |
| 3           | Adjustable bush     | R14/07-002-000                       | 1                      |             |
| 4           | Mounting plates     | R14/07-000-002                       | 2                      |             |
| 5           | Lever adjustment    | R14/07-000-001                       | 1                      |             |
| 6           | Elliptical sifter   | 2-09-643-380052                      | 2                      |             |
| 7           | Complete roll       | 2-09-643-580710                      | 2                      |             |
| 8           | Nut M20             | PN-86/M-82144                        | 2                      |             |
| 9           | Pad 21              | PN-78/M-82005                        | 2                      |             |
| 10          | Washer 20,5         | PN-77/M-82008                        | 2                      |             |
| 11          | Screw M8x25         | PN-85/M-82101                        | 2                      |             |
| 12          | Pad 8,4             | PN-78/M-82005                        | 6                      |             |
| 13          | Washer Z8.2         | PN-77/M-82008                        | 4                      |             |
| 14          | Nut M8              | PN-86/M-82144                        | 4                      |             |
| 15          | Screw M8x50         | PN-85/M-82101                        | 2                      |             |

# CHASSIS




TABLE 5

## Chassis

Table-5

| <i>Sin.</i> | <i>Name of part</i>              | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|----------------------------------|--------------------------------------|------------------------|-------------|
| 1           | Complete axle                    | R02/01-001-000                       | 1                      |             |
| 2           | Complete hub                     | R02/07-002-000                       | 2                      |             |
| 3           | Tire 4.00-10 IM-06               | 2-10-1200-115-2                      | 2                      |             |
| 4           | Tube 4.00/4,40-10                | 2-10-1100-114-2                      | 2                      |             |
| 5           | Rim I                            | 2-10-1300-103-6                      | 2                      |             |
| 6           | Rim II                           | 2-10-1300-103-6                      | 2                      |             |
| 7           | Cover of hub                     | 2-09-1600-004-0                      | 2                      |             |
| 8           | Planceta 6305                    | PN-85/M-86100                        | 2                      |             |
| 9           | Ring of settlements. compr. Z 25 | PN-85/M-85111                        | 2                      |             |
| 10          | Ring of settlements. compr. W 65 | PN-81/M-85111                        | 2                      |             |
| 11          | Planceta 6206                    | PN-85/M-86100                        | 2                      |             |
| 12          | Ring seal A 35x65x10             | PN-72/M-86965                        | 2                      |             |
| 13          | Nut M10-5-B Fe/Zn                | PN-86/M-82144                        | 8                      |             |
| 14          | Washer Z 10,2                    | PN-77/M-82008                        | 8                      |             |
| 15          | Pad                              | PN-78/M-82005                        | 16                     |             |
| 16          | Screw M10x30-5,6-B Fe/Zn         | PN-85/M-82101                        | 8                      |             |
| 17          | Screw M8x20-5,6-B Fe/Zn          | PN-85/M-82101                        | 12                     |             |
| 18          | Washer Z 8,2                     | PN-77/M-82008                        | 24                     |             |
| 19          | Pad 8                            | PN-78/M-82005                        | 24                     |             |
| 20          | Nut M8-5-B Fe/Zn                 | PN86/M-82144                         | 12                     |             |

## BELTS OF SIFTERS





TABLE 6.1





TABLE 6.2

TABLE 6

**LIST OF TABLES OF BELTS OF SIFTER**

| <b>Sin.</b> | <b>Name of tables</b>           | <b>Number of table</b> |
|-------------|---------------------------------|------------------------|
| <b>1.</b>   | <b>Belt of sifter I (lower)</b> | <b>Table-6.1</b>       |
| <b>2.</b>   | <b>Belt of sifter I (upper)</b> | <b>Table-6.2</b>       |


**BELT OF SIFTER 1****TABLE 6.1**



## Belt of sifter I

Table-6.1

| <i>Sin.</i> | <i>Name of part</i>      | <i>Symbol KTMor<br/>standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|--------------------------|-----------------------------------------|------------------------|-------------|
| 1           | Sifter rod I             | RP06/07-001-001                         | 73                     |             |
| 2           | Sifter rod II            | RP06/07-003-001                         | 2                      |             |
| 3           | Connecting rod           | RP06/07-000-001                         | 1                      |             |
| 4           | Side belt                | RP06/07-000-001                         | 2                      |             |
| 5           | Middle belt              | RP06/07-000-002                         | 1                      |             |
| 6           | Lagging connecting rod   | RP06/07-000-003                         | 2                      |             |
| 7           | Lagging sifter rod I, II | RP06/07-001-002                         | 146                    |             |
| 8           | Sifter nut I             | RP06/07-000-004                         | 221                    |             |
| 9           | Sifter nut II            | RP06/07-000-005                         | 8                      |             |
| 10          | Side half lock I         | RP06/07-000-006                         | 2                      |             |
| 11          | Side half lock II        | RP06/07-000-007                         | 2                      |             |
| 12          | Middle half lock I       | RP06/07-000-008                         | 1                      |             |
| 13          | Middle half lock II      | RP06/07-000-009                         | 1                      |             |
| 14          | Rivet 5x28               | PN-88/M-82954                           | 8                      |             |
| 15          | Rivet 5x24               | PN-88/M-82954                           | 8                      |             |
| 16          | Rivet 5x18               | PN-88/M-82954                           | 444                    |             |



Tablica - 6.2


## BELT OF SIFTER 2

TABLE 6.2

## Sifter belt II

Table-6.2

| <i>Sin.</i> | <i>Name of part</i>       | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|---------------------------|--------------------------------------|------------------------|-------------|
| 1           | Sifter rod I              | RP06/07-001-001                      | 41                     |             |
| 2           | Sifter rod II             | RP06/07-003-001                      | 2                      |             |
| 3           | Connecting rod            | RP06/07-000-010                      | 1                      |             |
| 4           | Side belt                 | RP06/07-000-001                      | 2                      |             |
| 5           | Middle belt               | RP06/07-000-002                      | 1                      |             |
| 6           | Lagging connecting rod    | RP06/07-000-003                      | 2                      |             |
| 7           | Lagging sifter rod. I, II | RP06/07-001-002                      | 146                    |             |
| 8           | Sifter nut I              | RP06/07-000-004                      | 125                    |             |
| 9           | Sifter nut II             | RP06/07-000-005                      | 8                      |             |
| 10          | Side half lock I          | RP06/07-000-006                      | 2                      |             |
| 11          | Side half lock II         | RP06/07-000-007                      | 2                      |             |
| 12          | Middle half lock I        | RP06/07-000-008                      | 1                      |             |
| 13          | Middle half lock II       | RP06/07-000-009                      | 1                      |             |
| 14          | Rivet 5x28                | PN-88/M-82954                        | 8                      |             |
| 15          | Rivet 5x24                | PN-88/M-82954                        | 8                      |             |
| 16          | Rivet 5x18                | PN-88/M-82954                        | 250                    |             |


**COULTER****TABLE 7**

## Coulter

Układ elektryczny

Table-7

| <i>Sin.</i> | <i>Name of part</i>      | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|--------------------------|--------------------------------------|------------------------|-------------|
| 1           | Coulter handle           | R08/07-001-000                       | 1                      |             |
| 2           | Hub                      | R08/01-000-001                       | 1                      |             |
| 3           | Cover                    | R08/01-000-004                       | 1                      |             |
| 4           | Shank                    | R08/07-000-001                       | 1                      |             |
| 5           | Axle of coulter          | R08/07-000-002                       | 1                      |             |
| 6           | Rolling coulter 500x85   | R08/07-000-003                       | 1                      |             |
| 7           | Planceta 6206            | PN-85/M-86100                        | 2                      |             |
| 8           | Ring of settlements W 65 | PN-81/M-85111                        | 3                      |             |
| 9           | Ring of settlements Z 30 | PN-81/M-85111                        | 1                      |             |
| 10          | Ring seals A 35x55x10    | PN-85/M-86965                        | 1                      |             |
| 11          | Spring circles 6x4       | PN-89/M-85021                        | 1                      |             |
| 12          | Screw M12x40             | PN-85/M-82101                        | 4                      |             |
| 13          | Nut M12                  | PN-86/M-82144                        | 4                      |             |
| 14          | Pad 13                   | PN-78/M-82005                        | 8                      |             |
| 15          | Washer 12.2              | PN-77/M-82008                        | 4                      |             |
| 16          | Washer 24.5              | PN-77/M-82008                        | 1                      |             |
| 17          | Nut M24                  | PN-86/M-82144                        | 1                      |             |
| 18          | Nut M16                  | PN-86/M-82144                        | 2                      |             |
| 19          | Screw M16x60             | PN-85/M-82101                        | 2                      |             |



## **ELECTRICAL SYSTEM**


**TABLE 8**

Electrical system

Table-8

| <i>Sin.</i> | <i>Name of part</i> | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|---------------------|--------------------------------------|------------------------|-------------|
| 1           | Left plate          | R05/07-000-001                       | 1                      |             |
| 2           | Right plate         | R05/07-000-002                       | 1                      |             |
| 3           | Plug 12N            | 2-10-5100-106-0                      | 1                      |             |
| 4           | Back lights         | 2-10-5100-103-0                      | 2                      |             |
| 5           | Red reflex          | PN-90/S-73100                        | 2                      |             |
| 6           | Cable I             |                                      | 3,5 m                  |             |
| 7           | Cable II            |                                      | 2 m                    |             |

Lemiesz



Tablica - 9

**BLADE**

**TABLE 9**



## Blade

Table-9

| <i>Sin.</i> | <i>Name of part</i>       | <i>Symbol KTM or standard number</i> | <i>Number of units</i> | <i>Note</i> |
|-------------|---------------------------|--------------------------------------|------------------------|-------------|
| 1           | Frame of blade            | R07/07-001-000                       | 1                      |             |
| 2           | Connecting rod            | R07/07-000-009                       | 2                      |             |
| 3           | Blade                     | R07/07-000-005                       | 2                      |             |
| 4           | Share point 5625/27-014/1 | 2-09-625-270141                      | 16                     |             |
| 5           | Screw M12                 | PN-EN-ISO 4759-1                     | 8                      |             |
| 6           | Pad 10,5                  | PN-78/M-82005                        | 2                      |             |
| 7           | Pad 12,2                  | PN-77/M-82008                        | 8                      |             |
| 8           | Nut M12                   | PN-86/M-82144                        | 8                      |             |
| 9           | Cotter pin S 4x25         | PN-76/M-82001                        | 2                      |             |

### Number reference of digger Z 653

| Sin.      | Name of part            | Symbol KTM<br>Or standards number | Number of<br>units | Pos. in<br>table | Table |
|-----------|-------------------------|-----------------------------------|--------------------|------------------|-------|
| <b>1</b>  | Frame                   | R01/10-001-000                    | 1                  | 1                | T-2   |
| <b>2</b>  | Box                     | R00/10-001-000                    | 1                  | 2                | T-2   |
| <b>3</b>  | Mudguard right          | R01/10-027-000                    | 1                  | 3                | T-2   |
| <b>4</b>  | Handle                  | R00/10-004-000                    | 2                  | 4                | T-2   |
| <b>5</b>  | Ladder II               | R01/10-013-000                    | 1                  | 5                | T-2   |
| <b>6</b>  | Ladder I                | R01/10-012-000                    | 1                  | 6                | T-2   |
| <b>7</b>  | Mudguard left           | R01/10-028-000                    | 1                  | 7                | T-2   |
| <b>8</b>  | Shaft                   | R03/07-000-001                    | 1                  | 1                | T-3.1 |
| <b>9</b>  | Pulley III              | R03/07-006-000                    | 1                  | 2                | T-3.1 |
| <b>10</b> | Bush                    | R03/07-000-002                    | 1                  | 3                | T-3.1 |
| <b>11</b> | Handle of chain I       | R03/01-003-000                    | 1                  | 4                | T-3.1 |
| <b>12</b> | Handle of chain II      | R03/01-004-000                    | 1                  | 5                | T-3.1 |
| <b>13</b> | Cover I                 | Laminate                          | 1                  | 6                | T-3.1 |
| <b>14</b> | Cover II                | Laminate                          | 1                  | 7                | T-3.1 |
| <b>15</b> | Binder P-206            | 2-09-1400-131-8                   | 2                  | 8                | T-3.1 |
| <b>16</b> | Clutch                  | 2-05-644-300256                   | 1                  | 9                | T-3.1 |
| <b>17</b> | Bevel-gear differential | 2-09-1400-131-8                   | 1                  | 10               | T-3.1 |
| <b>18</b> | Half pin 5/8-2-10B      | 2-08-047-003-4                    | 1                  | 11               | T-3.1 |
| <b>19</b> | Circlip 30              | PN-72/M-85101                     | 1                  | 12               | T-3.1 |
| <b>20</b> | Circlip compr.Z30       | PN-81/N-85111                     | 3                  | 13               | T-3.1 |
| <b>21</b> | V belt C2360            | PN-86/M-85200/06                  | 1                  | 14               | T-3.1 |
| <b>22</b> | Neck bolt M10x25        | PN-73/M-82406                     | 10                 | 15               | T-3.1 |
| <b>23</b> | Pad 8,4                 | PN-78/M-82005                     | 6                  | 16               | T-3.1 |
| <b>24</b> | Nut M10-5-B Fe/Zn       | PN-86/M-82144                     | 10                 | 17               | T-3.1 |
| <b>25</b> | Screw M8x25.6-B Fe/Zn   | PN-85/M-82101                     | 6                  | 18               | T-3.1 |
| <b>26</b> | Chain 108-2-17          | PN-77/M-84168                     |                    | 19               | T-3.1 |
| <b>27</b> | Drain prism. A 8x7x36   | PN-70/M-85005                     | 3                  | 20               | T-3.1 |
| <b>28</b> | Planceta FD-206         | PN-73/M-86120                     | 1                  | 21               | T-3.1 |
| <b>29</b> | Sifter shaft            | R03/07-001-001                    | 1                  | 1                | T-3.2 |

**36**

|           |                          |                  |    |    |       |
|-----------|--------------------------|------------------|----|----|-------|
| <b>30</b> | Drive wheel              | R06/01-007-002   | 2  | 2  | T-3.2 |
| <b>31</b> | Bush I                   | R03/07-001-002   | 2  | 3  | T-3.2 |
| <b>32</b> | Hub                      | R06/01-007-005   | 1  | 4  | T-3.2 |
| <b>33</b> | Pulley I                 | R03/07-004-000   | 2  | 5  | T-3.2 |
| <b>34</b> | Pulley II                | R03/07-005-000   | 1  | 6  | T-3.2 |
| <b>35</b> | Shield 5643/38-004/0     | 2-09-643-380-040 | 1  | 7  | T-3.2 |
| <b>36</b> | Cover P-207              | 2-09-1400-131-8  | 6  | 8  | T-3.2 |
| <b>37</b> | Drain prism A10x8x50     | PN-70/M-85005    | 2  | 9  | T-3.2 |
| <b>38</b> | Planceta FD 207          | PN-73/M-86120    | 2  | 10 | T-3.2 |
| <b>39</b> | Ścrew M10x25 Fe/Zn       | PN-73/M-82402    | 6  | 11 | T-3.2 |
| <b>40</b> | Nut M10-5-B              | PN-86/M-82144    | 16 | 12 | T-3.2 |
| <b>41</b> | Pad 10,5                 | PN-78/M-82005    | 34 | 13 | T-3.2 |
| <b>42</b> | Ścrew M8x30 Fe./Zn       | PN-85/M-82101    | 2  | 14 | T-3.2 |
| <b>43</b> | Nut M8-5-B               | PN-86/M-82144    | 2  | 15 | T-3.2 |
| <b>44</b> | Ścrew M10x40             | PN-85/M-82101    | 12 | 16 | T-3.2 |
| <b>45</b> | Ścrew M10x45             | PN-85/M82101     | 2  | 17 | T-3.2 |
| <b>46</b> | Drain prism A8x7x36      | PN-70/M-85005    | 3  | 18 | T-3.2 |
| <b>47</b> | ESP circlip .Z30         | PN-81/M-85111    | 3  | 19 | T-3.2 |
| <b>48</b> | Sifter shaft             | R03/07-002-001   | 1  | 1  | T-3.3 |
| <b>49</b> | Drive wheel              | R06/01-007-002   | 2  | 2  | T-3.3 |
| <b>50</b> | Bush I                   | R03/07-001-002   | 2  | 3  | T-3.3 |
| <b>51</b> | Hub                      | R06/01-007-005   | 1  | 4  | T-3.3 |
| <b>52</b> | Pulley I                 | R03/07-004-000   | 1  | 5  | T-3.3 |
| <b>53</b> | Shield 5643/38-004-0     | 2-09-643-380-040 | 1  | 6  | T-3.3 |
| <b>54</b> | Cover P-207              | 2-09-1400-131-8  | 6  | 7  | T-3.3 |
| <b>55</b> | Drain prism A10x8x50     | PMN-70/M-85005   | 2  | 8  | T-3.3 |
| <b>56</b> | Planceta FD 206          | PN-73/M-86120    | 2  | 9  | T-3.3 |
| <b>57</b> | Ścrew M10x25 Fe/Zn       | PN-73/M-82402    | 6  | 10 | T-3.3 |
| <b>58</b> | Nut M10-5-B              | PN-86/M-82144    | 16 | 11 | T-3.3 |
| <b>59</b> | Pad 10,5                 | PN-86/M-82005    | 34 | 12 | T-3.3 |
| <b>60</b> | Ścrew M10x40             | PN-85/M-82101    | 12 | 13 | T-3.3 |
| <b>61</b> | Ścrew M10x45-B 8-B Fe/Zn | PN-85/M-82101    | 2  | 14 | T-3.3 |
| <b>62</b> | Drain prism A 8x7x36     | PN-70/M-85005    | 3  | 15 | T-3.3 |
| <b>63</b> | ESP circlip Z30          | PN-81/M-85111    | 2  |    | T-3.3 |
| <b>64</b> | V belt C2360             | PN-86/M-85200/06 | 1  | 16 | T-3.3 |
| <b>65</b> | Roll                     | R03/01-006-001   | 1  | 1  | T-3.4 |

### 37

|            |                     |                   |   |    |       |
|------------|---------------------|-------------------|---|----|-------|
| <b>66</b>  | Shaft               | R03/07-007-001    | 1 | 2  | T-3.4 |
| <b>67</b>  | Bush                | R03/01-006-003    | 1 | 3  | T-3.4 |
| <b>68</b>  | Handle              | R03/07-010-000    | 1 | 4  | T-3.4 |
| <b>69</b>  | Circlip W47         | PN-81/M-85111     | 2 | 5  | T-3.4 |
| <b>70</b>  | Planceta 6005       | PN-85/M-86100     | 2 | 6  | T-3.4 |
| <b>71</b>  | Nut M16             | PN-86/M-82144     | 1 | 7  | T-3.4 |
| <b>72</b>  | Pad 17              | PN-77/M-82005     | 1 | 8  | T-3.4 |
| <b>73</b>  | Grease M10          | PN-76/M-86007     | 1 | 9  | T-3.4 |
| <b>74</b>  | Axle                | R03/07-003-001    | 1 | 1  | T-3.5 |
| <b>75</b>  | Bush                | R03/07-003-002    | 1 | 2  | T-3.5 |
| <b>76</b>  | Handle              | R03/07-009-000    | 1 | 3  | T-3.5 |
| <b>77</b>  | Roll                | 2-09-644-51-08-90 | 1 | 4  | T-3.5 |
| <b>78</b>  | Planceta 6004       | PN-85/M-86100     | 1 | 5  | T-3.5 |
| <b>79</b>  | Circlip W42         | PN-81/M-85111     | 1 | 6  | T-3.5 |
| <b>80</b>  | Pad 17              | PN-77/M-82005     | 1 | 7  | T-3.5 |
| <b>81</b>  | Nut M16             | PN-86/M-82144     | 1 | 8  | T-3.5 |
| <b>82</b>  | Shaft of sifter     | R14/07-001-000    | 1 | 1  | T-4   |
| <b>83</b>  | Cover               | R14/07-003-000    | 1 | 2  | T-4   |
| <b>84</b>  | Adjustable bush     | R14/07-002-000    | 1 | 3  | T-4   |
| <b>85</b>  | Mounting plate      | R14/07-000-002    | 2 | 4  | T-4   |
| <b>86</b>  | Adjustment lever    | R14/07-000-001    | 1 | 5  | T-4   |
| <b>87</b>  | Epilleptical sifter | 2-09-643-380052   | 2 | 6  | T-4   |
| <b>88</b>  | Complete roll       | 2-09-643-580710   | 2 | 7  | T-4   |
| <b>89</b>  | Nut M20             | PN-86/M-82144     | 2 | 8  | T-4   |
| <b>90</b>  | Pad 21              | PN-78/M-82005     | 2 | 9  | T-4   |
| <b>91</b>  | Washer 20,5         | PN-77/M-82008     | 2 | 10 | T-4   |
| <b>92</b>  | Screw M8x25         | PN-85/M-82101     | 2 | 11 | T-4   |
| <b>93</b>  | Pad 8,4             | PN-78/M-82005     | 6 | 12 | T-4   |
| <b>94</b>  | Washer Z8.2         | PN-77/M-82008     | 4 | 13 | T-4   |
| <b>95</b>  | Nut M8              | PN-86/M-82144     | 4 | 14 | T-4   |
| <b>96</b>  | Screw M8x50         | PN-85/M-82101     | 2 | 15 | T-4   |
| <b>97</b>  | Complete axle       | R02/01-001-000    | 1 | 1  | T-5   |
| <b>98</b>  | Complete hub        | R02/07-002-000    | 2 | 2  | T-5   |
| <b>99</b>  | Tire 4.00-10 IM-06  | 2-10-1200-115-2   | 2 | 3  | T-5   |
| <b>100</b> | Tube 4.00/4,40-10   | 2-10-1100-114-2   | 2 | 4  | T-5   |
| <b>101</b> | Rim I               | 2-10-1300-103-6   | 2 | 5  | T-5   |

**38**

|            |                           |                 |     |    |       |
|------------|---------------------------|-----------------|-----|----|-------|
| <b>102</b> | Rim II                    | 2-10-1300-103-6 | 2   | 6  | T-5   |
| <b>103</b> | Cover of hub              | 2-09-1600-004-0 | 2   | 7  | T-5   |
| <b>104</b> | Planceta 6305             | PN-85/M-86100   | 2   | 8  | T-5   |
| <b>105</b> | ESP circlip. Z 25         | PN-85/M-85111   | 2   | 9  | T-5   |
| <b>106</b> | ESP cieclip W 65          | PN-81/M-85111   | 2   | 10 | T-5   |
| <b>107</b> | Planceta 6206             | PN-85/M-86100   | 2   | 11 | T-5   |
| <b>108</b> | Seal ring A 35x65x10      | PN-72/M-86965   | 2   | 12 | T-5   |
| <b>109</b> | Nut M10-5-B Fe/Zn         | PN-86/M-82144   | 8   | 13 | T-5   |
| <b>110</b> | Washer Z 10,2             | PN-77/M-82008   | 8   | 14 | T-5   |
| <b>111</b> | Pad                       | PN-78/M-82005   | 16  | 15 | T-5   |
| <b>112</b> | Screw M10x30-5,6-B Fe/Zn  | PN-85/M-82101   | 8   | 16 | T-5   |
| <b>113</b> | Screw M8x20-5,6-B Fe/Zn   | PN-85/M-82101   | 12  | 17 | T-5   |
| <b>114</b> | Washer Z 8,2              | PN-77/M-82008   | 24  | 18 | T-5   |
| <b>115</b> | Pad 8                     | PN-78/M-82005   | 24  | 19 | T-5   |
| <b>116</b> | Nut M8-5-B Fe/Zn          | PN-86/M-82144   | 12  | 20 | T-5   |
| <b>117</b> | Sifter rod I              | RP06/07-001-001 | 73  | 1  | T-6.1 |
| <b>118</b> | Sifter rod II             | RP06/07-003-001 | 2   | 2  | T-6.1 |
| <b>119</b> | Connecting rod            | RP06/07-000-010 | 1   | 3  | T-6.1 |
| <b>120</b> | Side belt                 | RP06/07-000-001 | 2   | 4  | T-6.1 |
| <b>121</b> | Middle belt               | RP06/07-000-002 | 1   | 5  | T-6.1 |
| <b>122</b> | Lagging connecting rod    | RP06/07-000-003 | 2   | 6  | T-6.1 |
| <b>123</b> | Lagging sifter rod. I, II | RP06/07-001-002 | 146 | 7  | T-6.1 |
| <b>124</b> | Sifter nut I              | RP06/07-000-004 | 221 | 8  | T-6.1 |
| <b>125</b> | Sifter rod II             | RP06/07-000-005 | 8   | 9  | T-6.1 |
| <b>126</b> | Side half lock I          | RP06/07-000-006 | 2   | 10 | T-6.1 |
| <b>127</b> | Side half lock II         | RP06/07-000-007 | 2   | 11 | T-6.1 |
| <b>128</b> | Middle half lock I        | RP06/07-000-008 | 1   | 12 | T-6.1 |
| <b>129</b> | Middle half lock II       | RP06/07-000-009 | 1   | 13 | T-6.1 |
| <b>130</b> | Rivet 5x28                | PN-88/M-82954   | 8   | 14 | T-6.1 |
| <b>131</b> | Rivet 5x24                | PN-88/M-82954   | 8   | 15 | T-6.1 |
| <b>132</b> | Rivet 5x18                | PN-88/M-82954   | 444 | 16 | T-6.1 |
| <b>133</b> | Sifter rod I              | RP06/07-001-001 | 41  | 1  | T-6.2 |
| <b>134</b> | Sifter rod II             | RP06/07-003-001 | 2   | 2  | T-6.2 |
| <b>135</b> | Connecting rod            | RP06/07-000-010 | 1   | 3  | T-6.2 |
| <b>136</b> | Side belt                 | RP06/07-000-001 | 2   | 4  | T-6.2 |
| <b>137</b> | Middle belt               | RP06/07-000-002 | 1   | 5  | T-6.2 |

### 39

|            |                           |                 |       |    |       |
|------------|---------------------------|-----------------|-------|----|-------|
| <b>138</b> | Lagging connecting rod    | RP06/07-000-003 | 2     | 6  | T-6.2 |
| <b>139</b> | Lagging sifter rod I, II  | RP06/07-001-002 | 146   | 7  | T-6.2 |
| <b>140</b> | Sifter nut I              | RP06/07-000-004 | 125   | 8  | T-6.2 |
| <b>141</b> | Sifter nut II             | RP06/07-000-005 | 8     | 9  | T-6.2 |
| <b>142</b> | Side half lock I          | RP06/07-000-006 | 2     | 10 | T-6.2 |
| <b>143</b> | Side half lock II         | RP06/07-000-007 | 2     | 11 | T-6.2 |
| <b>144</b> | Middle half lock I        | RP06/07-000-008 | 1     | 12 | T-6.2 |
| <b>145</b> | Middle half lock II       | RP06/07-000-009 | 1     | 13 | T-6.2 |
| <b>146</b> | Rivet 5x28                | PN-88/M-82954   | 8     | 14 | T-6.2 |
| <b>147</b> | Rivet 5x24                | PN-88/M-82954   | 8     | 15 | T-6.2 |
| <b>148</b> | Rivet 5x18                | PN-88/M-82954   | 250   | 16 | T-6.2 |
| <b>149</b> | Coulter handle            | R08/07-001-000  | 1     | 1  | T-7   |
| <b>150</b> | Hub                       | R08/01-000-001  | 1     | 2  | T-7   |
| <b>151</b> | Cover                     | R08/01-000-004  | 1     | 3  | T-7   |
| <b>152</b> | Shank                     | R08/07-000-001  | 1     | 4  | T-7   |
| <b>153</b> | Coulter axle              | R08/07-000-002  | 1     | 5  | T-7   |
| <b>154</b> | Coulter 500x85            | R08/07-000-003  | 1     | 6  | T-7   |
| <b>155</b> | Planceta 6206             | PN-85/M-86100   | 2     | 7  | T-7   |
| <b>156</b> | Ring of settlements. W 65 | PN-81/M-85111   | 3     | 8  | T-7   |
| <b>157</b> | Ring of settlements. Z 30 | PN-81/M-85111   | 1     | 9  | T-7   |
| <b>158</b> | Ring seals. A 35x55x10    | PN-85/M-86965   | 1     | 10 | T-7   |
| <b>159</b> | Spring circles 6x4        | PN-89/M-85021   | 1     | 11 | T-7   |
| <b>160</b> | Screw M12x40              | PN-85/M-82101   | 4     | 12 | T-7   |
| <b>161</b> | Nut M12                   | PN-86/M-82144   | 4     | 13 | T-7   |
| <b>162</b> | Pad 13                    | PN-78/M-82005   | 8     | 14 | T-7   |
| <b>163</b> | Washer 12.2               | PN-77/M-82008   | 4     | 15 | T-7   |
| <b>164</b> | Washer 24.5               | PN-77/M-82008   | 1     | 16 | T-7   |
| <b>165</b> | Nut M24                   | PN-86/M-82144   | 1     | 17 | T-7   |
| <b>166</b> | Nut M16                   | PN-86/M-82144   | 2     | 18 | T-7   |
| <b>167</b> | Screw M16x60              | PN-85/M-82101   | 2     | 19 | T-7   |
| <b>168</b> | Left plate                | R05/07-000-001  | 1     | 1  | T-8   |
| <b>169</b> | Right plate               | R05/07-000-002  | 1     | 2  | T-8   |
| <b>170</b> | Plug 12N                  | 2-10-5100-106-0 | 1     | 3  | T-8   |
| <b>171</b> | Back light                | 2-10-5100-103-0 | 2     | 4  | T-8   |
| <b>172</b> | Red reflex                | PN-90/S-73100   | 2     | 5  | T-8   |
| <b>173</b> | Cable I                   |                 | 3,5 m | 6  | T-8   |

**40**

|            |                           |                  |     |   |     |
|------------|---------------------------|------------------|-----|---|-----|
| <b>174</b> | Cable II                  |                  | 2 m | 7 | T-8 |
| <b>175</b> | Frame of blade            | R07/07-001-000   | 1   | 1 | T-9 |
| <b>176</b> | Connecting rod            | R07/07-000-009   | 2   | 2 | T-9 |
| <b>177</b> | Blade                     | R07/07-000-005   | 2   | 3 | T-9 |
| <b>178</b> | Share point 5625/27-014/1 | 2-09-625-270141  | 16  | 4 | T-9 |
| <b>179</b> | Screw M12                 | PN-EN-ISO 4759-1 | 8   | 5 | T-9 |
| <b>180</b> | Pad 10,5                  | PN-78/M-82005    | 2   | 6 | T-9 |
| <b>181</b> | Pad 12,2                  | PN-77/M-82008    | 8   | 7 | T-9 |
| <b>182</b> | Nut M12                   | PN-86/M-82144    | 8   | 8 | T-9 |
| <b>183</b> | Cotter S 4x25             | PN-76/M-82001    | 2   | 9 | T-9 |

## List of standard parts Of digger Z 653

| Sin.      | Name of part             | Symbol KTM<br>Or standard number | Number of<br>units | Pos. in<br>table | Table |
|-----------|--------------------------|----------------------------------|--------------------|------------------|-------|
| <b>1</b>  | Circlip 30               | PN-72/M-85101                    | 1                  | 12               | T-3.1 |
| <b>2</b>  | ESP circlip Z30          | PN-81/N-85111                    | 3                  | 13               | T-3.1 |
| <b>3</b>  | V belt C2360             | PN-86/M-85200/06                 | 1                  | 14               | T-3.1 |
| <b>4</b>  | Neck bolt M10x25         | PN-73/M-82406                    | 10                 | 15               | T-3.1 |
| <b>5</b>  | Pad 8,4                  | PN-78/M-82005                    | 6                  | 16               | T-3.1 |
| <b>6</b>  | Nut M10-5-B Fe/Zn        | PN-86/M-82144                    | 10                 | 17               | T-3.1 |
| <b>7</b>  | Screw M8x25.6-B Fe/Zn    | PN-85/M-82101                    | 6                  | 18               | T-3.1 |
| <b>8</b>  | Chain 108-2-17           | PN-77/M-84168                    |                    | 19               | T-3.1 |
| <b>9</b>  | Drain prism A 8x7x36     | PN-70/M-85005                    | 3                  | 20               | T-3.1 |
| <b>10</b> | Planceta FD-206          | PN-73/M-86120                    | 1                  | 21               | T-3.1 |
| <b>11</b> | Drain prism A10x8x50     | PN-70/M-85005                    | 2                  | 9                | T-3.2 |
| <b>12</b> | Planceta FD 207          | PN-73/M-86120                    | 2                  | 10               | T-3.2 |
| <b>13</b> | Neck bolt M10x25         | PN-73/M-82402                    | 6                  | 11               | T-3.2 |
| <b>14</b> | Nut M10-5-B              | PN-86/M-82144                    | 16                 | 12               | T-3.2 |
| <b>15</b> | Pad 10,5                 | PN-78/M-82005                    | 34                 | 13               | T-3.2 |
| <b>16</b> | Screw M8x30 Fe./Zn       | PN-85/M-82101                    | 2                  | 14               | T-3.2 |
| <b>17</b> | Nut M8-5-B               | PN-86/M-82144                    | 2                  | 15               | T-3.2 |
| <b>18</b> | Screw M10x40             | PN-85/M-82101                    | 12                 | 16               | T-3.2 |
| <b>19</b> | Screw M10x45             | PN-85/M82101                     | 2                  | 17               | T-3.2 |
| <b>20</b> | Drain prism A8x7x36      | PN-70/M-85005                    | 3                  | 18               | T-3.2 |
| <b>21</b> | ESP circlip .Z30         | PN-81/M-85111                    | 3                  | 19               | T-3.2 |
| <b>22</b> | Drain prism A10x8x50     | PMN-70/M-85005                   | 2                  | 8                | T-3.3 |
| <b>23</b> | Planceta FD 206          | PN-73/M-86120                    | 2                  | 9                | T-3.3 |
| <b>24</b> | Neck bolt M10x25         | PN-73/M-82402                    | 6                  | 10               | T-3.3 |
| <b>25</b> | Nut M10-5-B              | PN-86/M-82144                    | 16                 | 11               | T-3.3 |
| <b>26</b> | Pad 10,5                 | PN-86/M-82005                    | 34                 | 12               | T-3.3 |
| <b>27</b> | Screw M10x40             | PN-85/M-82101                    | 12                 | 13               | T-3.3 |
| <b>28</b> | Screw M10x45-B 8-B Fe/Zn | PN-85/M-82101                    | 2                  | 14               | T-3.3 |
| <b>29</b> | Drain prism A 8x7x36     | PN-70/M-85005                    | 3                  | 15               | T-3.3 |
| <b>30</b> | ESP circlip Z30          | PN-81/M-85111                    | 2                  | 16               | T-3.3 |



|    |                                  |                  |     |    |       |
|----|----------------------------------|------------------|-----|----|-------|
| 31 | V belt C2360                     | PN-86/M-85200/06 | 1   | 17 | T-3.3 |
| 32 | Circlip W47                      | PN-81/M-85111    | 2   | 5  | T-3.4 |
| 33 | Planceta 6005                    | PN-85/M-86100    | 2   | 6  | T-3.4 |
| 34 | Nut M16                          | PN-86/M-82144    | 1   | 7  | T-3.4 |
| 35 | Pad 17                           | PN-77/M-82005    | 1   | 8  | T-3.4 |
| 36 | Grease M10                       | PN-76/M-86007    | 1   | 9  | T-3.4 |
| 37 | Planceta 6004                    | PN-85/M-86100    | 1   | 5  | T-3.5 |
| 38 | Circlip W42                      | PN-81/M-85111    | 1   | 6  | T-3.5 |
| 39 | Pad 17                           | PN-77/M-82005    | 1   | 7  | T-3.5 |
| 40 | Nut M16                          | PN-86/M-82144    | 1   | 8  | T-3.5 |
| 41 | Nut M20                          | PN-86/M-82144    | 2   | 8  | T-4   |
| 42 | Pad 21                           | PN-78/M-82005    | 2   | 9  | T-4   |
| 43 | Washer 20,5                      | PN-77/M-82008    | 2   | 10 | T-4   |
| 44 | Ścrew M8x25                      | PN-85/M-82101    | 2   | 11 | T-4   |
| 45 | Pad 8,4                          | PN-78/M-82005    | 6   | 12 | T-4   |
| 46 | Washer Z8.2                      | PN-77/M-82008    | 4   | 13 | T-4   |
| 47 | Nut M8                           | PN-86/M-82144    | 4   | 14 | T-4   |
| 48 | Ścrew M8x50                      | PN-85/M-82101    | 2   | 15 | T-4   |
| 49 | Planceta 6305                    | PN-85/M-86100    | 2   | 8  | T-5   |
| 50 | Ring of settlements. Compr.Z 25  | PN-85/M-85111    | 2   | 9  | T-5   |
| 51 | Ring of settlements. Compr. W 65 | PN-81/M-85111    | 2   | 10 | T-5   |
| 52 | Planceta 6206                    | PN-85/M-86100    | 2   | 11 | T-5   |
| 53 | Ring seal. A 35x65x10            | PN-72/M-86965    | 2   | 12 | T-5   |
| 54 | Nut M10-5-B Fe/Zn                | PN-86/M-82144    | 8   | 13 | T-5   |
| 55 | Washer Z 10,2                    | PN-77/M-82008    | 8   | 14 | T-5   |
| 56 | Pad                              | PN-78/M-82005    | 16  | 15 | T-5   |
| 57 | Ścrew M10x30-5,6-B Fe/Zn         | PN-85/M-82101    | 8   | 16 | T-5   |
| 58 | Ścrew M8x20-5,6-B Fe/Zn          | PN-85/M-82101    | 12  | 17 | T-5   |
| 59 | Washer Z 8,2                     | PN-77/M-82008    | 24  | 18 | T-5   |
| 60 | Podkładka 8                      | PN-78/M-82005    | 24  | 19 | T-5   |
| 61 | Nut M8-5-B Fe/Zn                 | PN-86/M-82144    | 12  | 20 | T-5   |
| 62 | Rivet 5x28                       | PN-88/M-82954    | 8   | 14 | T-6.1 |
| 63 | Rivet 5x24                       | PN-88/M-82954    | 8   | 15 | T-6.1 |
| 64 | Rivet 5x18                       | PN-88/M-82954    | 444 | 16 | T-6.1 |
| 65 | Rivet 5x28                       | PN-88/M-82954    | 8   | 14 | T-6.2 |
| 66 | Rivet 5x24                       | PN-88/M-82954    | 8   | 15 | T-6.2 |

**43**

|           |                          |                  |     |    |       |
|-----------|--------------------------|------------------|-----|----|-------|
| <b>67</b> | Rivet 5x18               | PN-88/M-82954    | 250 | 16 | T-6.2 |
| <b>68</b> | Planceta 6206            | PN-85/M-86100    | 2   | 7  | T-7   |
| <b>69</b> | Ring of settlements.W 65 | PN-81/M-85111    | 3   | 8  | T-7   |
| <b>70</b> | Ring of settlements.Z 30 | PN-81/M-85111    | 1   | 9  | T-7   |
| <b>71</b> | Ring seals.A 35x55x10    | PN-85/M-86965    | 1   | 10 | T-7   |
| <b>72</b> | Spring circles 6x4       | PN-89/M-85021    | 1   | 11 | T-7   |
| <b>73</b> | Screw M12x40             | PN-85/M-82101    | 4   | 12 | T-7   |
| <b>74</b> | Nut M12                  | PN-86/M-82144    | 4   | 13 | T-7   |
| <b>75</b> | Pad 13                   | PN-78/M-82005    | 8   | 14 | T-7   |
| <b>76</b> | Washer 12.2              | PN-77/M-82008    | 4   | 15 | T-7   |
| <b>77</b> | Washer 24.5              | PN-77/M-82008    | 1   | 16 | T-7   |
| <b>78</b> | Nut M24                  | PN-86/M-82144    | 1   | 17 | T-7   |
| <b>79</b> | Nut M16                  | PN-86/M-82144    | 2   | 18 | T-7   |
| <b>80</b> | Screw M16x60             | PN-85/M-82101    | 2   | 19 | T-7   |
| <b>81</b> | Red reflex               | PN-90/S-73100    | 2   | 5  | T-8   |
| <b>82</b> | Screw M12                | PN-EN-ISO 4759-1 | 8   | 5  | T-9   |
| <b>83</b> | Pad 10,5                 | PN-78/M-82005    | 2   | 6  | T-9   |
| <b>84</b> | Pad 12,2                 | PN-77/M-82008    | 8   | 7  | T-9   |
| <b>85</b> | Nut M12                  | PN-86/M-82144    | 8   | 8  | T-9   |
| <b>86</b> | Cotter S 4x25            | PN-76/M-82001    | 2   | 9  | T-9   |